

WHEEL AND TIRE ASSEMBLY

| ITEM | DESCRIPTION | PART NO. | REQ'D |
|------|-----------------------------|------------|-------|
| - | WHEEL ASSEMBLY | 1403-00 | 1 |
| 1. | HEX HEAD CAPSCREW | 1403-0008 | 8 |
| 2. | LOCKWASHER | 1403-0009 | 8 |
| 3. | HUB CAP | 1403-0006 | 1 |
| 4. | HUB CAP GASKET | 1403-0007 | 1 |
| 5. | NUT | 1266-2712 | 2 |
| 6. | LOCKWASHER | 1266-2713 | 2 |
| 7. | HEX HEAD BOLT | 1403-0005 | 16 |
| 8. | LOCK RING | 1403-02 | 1 |
| 9. | O-RING | 1403-0002 | 1 |
| 10. | BEAD SEAT BAND | 1403-03 | 2 |
| 11. | FLANGE | 1403-0001 | 2 |
| 12. | OUTER BEARING | 1266-2708 | 1 |
| 13. | RIM AND HUB | 1403-01 | 1 |
| 14. | INNER AND OUTER BEARING CUP | 1266-2707 | 2 |
| 15. | INNER BEARING CONE | 1266-2709 | 1 |
| 16. | GREASE RETAINER | 1266-2710 | 1 |
| 17. | FELT | 1266-2711 | 1 |
| 18. | TIRE, 36:00 x 51-42 PR | 1266-2716A | 1 |
| 19. | HEX HEAD BOLT AND NUT | 1403-0003 | 36 |
| 20. | QUICK DISCONNECT, FEMALE | 1403-0012 | 1 |
| 21. | CLOSE NIPPLE | 1403-0011 | 1 |
| 22. | GLOBE VALVE | 1403-0010 | 1 |
| 23. | GAUGE, 0-100 PSI | 1403-0017 | 1 |
| 24. | TEE | 1403-00161 | 1 |
| 25. | BUSHING | 1403-0018 | 1 |
| 26. | TIRE VALVE | 1403-0019 | 1 |
| 27. | LONG NIPPLE | 1403-0014 | 1 |
| 28. | GLOBE VALVE | 1403-0015 | 1 |
| 29. | LONG NIPPLE | 1403-0013 | 1 |
| 30. | JACKSCREW | 1403-0004 | 8 |