

☐

I'm not robot


reCAPTCHA

I am not robot!

Onn bluetooth speaker quick start guide pdf

We and our partners use cookies to Store and/or access information on a device. We and our partners use data for Personalised ads and content, ad and content measurement, audience insights and product development. An example of data being processed may be a unique identifier stored in a cookie. Some of our partners may process your data as a part of their legitimate business interest without asking for consent. To view the purposes they believe they have legitimate interest for, or to object to this data processing use the vendor list link below. The consent submitted will only be used for data processing originating from this website. If you would like to change your settings or withdraw consent at any time, the link to do so is in our privacy policy accessible from our home page.. Continue with Recommended Cookies To get instruction manuals, help guides, or download PDF documents, please select your model in the list below, or type the model name in the search box. 05 06To preserve battery lifespan, fully charge at least onceevery 45 days.It takes about four hours to fully charge.010402Short press “ ” button to execute play and pause. Short press volume “-” to reduce volume.Long press volume “-” to previous song.Short press volume “+” to increase volume.Long press volume “+” to next song.Need help? We’re here for you every day from 7 a.m. – 9 p.m. CST. Give us a call at 1-888-516-26302.0sSmall Rugged SpeakerSmall Rugged SpeakerQuick Start Guide8080*5P3.0s1.0s03Short press “ ” button to answer incoming calls.Short press “ ” to end the call.Long press “ ” button for 3s to reject a call.2.0s1.0s2.0s1.0sWir elessWir eless c an be fou ndAvai lable e quipm entonn. Rugged Speaker S2Press “ ” “ ” for 3s, all pairing records will be clearedand restore default volume.Press “ ” for 10s, The speaker can be reset.Short press two timesStart voice assistantPress “ ” button for 2s to turn on or turn o. We’d love to hear from you. Scan with your Walmart app and let usknow what you think. ©2022 Walmartonn. is a trademark of Walmart All Rights Reserved.6 78 1 1 3 1 4 1 6 0 4AABLSV100081918TWS2131. Bluetooth Speaker2. StrapTMQuick Start Guide3. Charging Cable4. Quick Start Guide1. Power2. Bluetooth3. broadcast4. Volume -5. Play / Pause6. Volume +7. AUX port8. Charging port42 35467810.0s3.0sShort press “ ” button to activate the bluetooth device. Use phone to search device’s pairing name “ onn. Rugged Speaker S “, click pairing name for connection and pairing.



Give us a call at 1-888-516-26302.0sSmall Rugged SpeakerSmall Rugged SpeakerQuick Start Guide8080*5P3.0s1.0s03Short press “ ” button to answer incoming calls.Short press “ ” to end the call.Long press “ ” button for 3s to reject a call.2.0s1.0s2.0s1.0sWir elessWir eless c an be fou ndAvai lable e quipm entonn. Rugged Speaker S2Press “ ” “ ” for 3s, all pairing records will be clearedand restore default volume.Press “ ” for 10s, The speaker can be reset.Short press two timesStart voice assistantPress “ ” button for 2s to turn on or turn o. We’d love to hear from you. Scan with your Walmart app and let usknow what you think. ©2022 Walmartonn. is a trademark of Walmart All Rights Reserved.6 78 1 1 3 1 4 1 6 0 4AABLSV100081918TWS2131. Bluetooth Speaker2. StrapTMQuick Start Guide3. Charging Cable4. Quick Start Guide1. Power2. Bluetooth3. broadcast4. Volume -5. Play / Pause6. Volume +7. AUX port8. Charging port42 35467810.0s3.0sShort press “ ” button to activate the bluetooth device. Use phone to search device’s pairing name “ onn. Rugged Speaker S “, click pairing name for connection and pairing. 3.0sTWS2Short press two times1.0sPower on two speakers at the same time, and wait for prompt tone “ Searching for connection ” from both speakers. Then choose one of the speakers as primary, and long press “ ” button for 3s to enter TWS pairing mode. You will hear “ left channel, right channel ” and now the two speakers are paired. Use your mobile device to pair with the primary speaker by Bluetooth pairing method, you are now able to play audio in unison using your mobile device. In addition, press “ ” button two times will disconnect the TWS.DC5VThe battery is charging LED Red On Full chargedLED Red O 05 06Clear pairing records and reset speaker Charging and connect outside audioPress “ ” for 5s, all pairing records will be cleared.In case you face any difficulties with your product, simply insert an insulated pointed object (eg-toothpick) inside the reset key to restart & reboot your device.What’s in the Box?0104PairingLight modeGet to Know LED Speaker02Play musicShort press “ ” button to execute play and pause. Short press volume “-” to reduce volume.Long press volume “-” to previous song.Short press volume “+” to increase volume.Long press volume “+” to next song.Need help? We’re here for you every day from 7 a.m. – 9 p.m. CST. Give us a call at 1-888-516-2630DC5V5.0sLightShort press x1Lighting eect switchShort press x2Lighting on / oShort press 5sStart / Close alarm 2.0sThis packing listdoes not includethis auxiliary insulator The battery is charging LED Red On Full chargedLED Red O We do not recommend using a USB charging devicethat is not 5V DC output.To preserve battery lifespan, fully charge at least onceevery 45 days.2Bluetooth will be activated upon powering on the device. Use phone to search device’s pairingname “ onn. LED SPK GRY “, Click pairing name for connection and pairing. LED SpeakerQuick Start Guide8080*5PWe’d love to hear from you. Scan with your Walmart app and let usknow what you think. ©2021 Walmartonn. is a trademark of Walmart All Rights Reserved.2.0s1.0s03Answer/End/Reject a callShort press “ ” button to answer incoming calls.Short press “ ” to end the call.Long press “ ” button for 2s to reject a call.Wir elessWir eless c an be fou ndAvai lable e quipm entonn .LED SPK GRY 131. Bluetooth Speaker2. StrapTMQuick Start Guide3. Charging Cable4. Quick Start Guide445671231. Light key 2. Volume -3. Volume +4. Power 5. Charging indicator6. Charging port7. Reset keyShort press x3Start / Close Siri1.0s2.0s1.0s2.0s1.0s1.0sDisconnect /Reconnect Bluetooth6 88 1 1 3 1 4 1 5 4 0AAGRY100076371 This webpage was generated by the domain owner using Sedo Domain Parking. Disclaimer: Sedo maintains no relationship with third party advertisers. Reference to any specific service or trade mark is not controlled by Sedo nor does it constitute or imply its association, endorsement or recommendation.