




Numbers shown next to transformer windings are DC resistance in ohms.



Note:
There is no internal connection to the +40 binding post.
B+ is connected to the plate of the output tube through the horn speaker or headphones.



The information presented is believed to be correct.
However, it is subject to revision at any time.

This information is based on examination of actual units.

All dimensions in inches All dimensions nominal.	W3NLB		(c) 2004-2006 W3NLB All Rights Reserved	
	Atwater Kent 4030 1-Stage Amplifier Schematic and Wiring Diagram			
Drawn by:	Leigh Bassett W3NLB	FSCM NO	DWG NO	REV
Date:	13 Dec 2006		AK04030SCH	A
SCALE		SHEET		1 OF 1