



## INSTALLATION GUIDE



**BATTERY TERMINALS**

Connect to **BATTERY TERMINALS**


- **ORANGE** Wire to (+) Positive Battery Terminal
- **BLACK** Wire to (-) Negative Battery Terminal



**LOUD HORN CONNECTORS**

Connect to **AFTERMARKET LOUD HORNS**

- **BLACK** Wire to (-) Negative Terminal
- **ORANGE** Wire to (+) Positive terminal



**TO STOCK HORN TRIGGERS**

Connect to **STOCK HORN TRIGGERS**

- **GREEN** Wire to (+) Positive trigger
- **BROWN** Wire to (-) Negative trigger