HOSE KIT IMCO 2 PUMP W/CRIMP HOSE BY HAVING IMCO MAKE YOUR HOSE ASSEMBLIES FOR YOU, YOU'LL SAVE TIME, MONEY AND YOU CAN REST ASSURED KNOWING THE HOSE ASSEMBLIES WON'T FAIL! THIS HOSE AND THESE HOSE ASSEMBLIES ARE ABSOLUTLY THE VERY BEST YOU CAN BUY.

QTY	P/N	KIT
1		HOSE KIT IMCO 2 PUMP W/CRIMP HOSE AND RESERVIOR TANK
4	FA-13	PARTS INCLUDED ADAPTER 3/4-16 O-RING TO -8 JIC ZPS
4	HO-3	HOSE END HP CRIMP 3/8" TO -6 JIC SS
2	FA-5	HOSE END LP 3/8" TO -6 JIC BRASS
6	HO-9	HOSE END HP CRIMP 1/2" TO -8 JIC SS
2	FA-4	HOSE END LP 1/2" TO -8 JIC BRASS
1	PT-13	VALVE ASSEMBLY 2 PUMP
1	PT-30	OIL TANK ASSEMBLY 1 OR 2 PUMP RESERVOIR
2	PT-10	PUMP CAP ASSEMBLY
		ADDITIONAL ITEMS NEEDED TO COMPLETE THIS KIT
1	?	HELM CONTROL, FOR CHOOSING THE CORRECT HELM DISPLACEMENT REFER TO (STEERING WHEEL TURNS LOCK TO LOCK) NOTE: 3 TO 4 TURNS IS STANDARD
1	?	HELM POST, THIS IS DETERMINED BY REACH WHILE SITTING IN THE DRIVERS SEAT, REFER TO HELM POSTS FOR CHOOSING THE ONE THAT WORKS BEST FOR YOU
	" НО-2	HOSE LP 3/8" TOTAL INCHES FROM CHART BELOW
	" НО-13	HOSE HP CRIMP 3/8" TOTAL INCHES FROM CHART BELOW
	" НО-5	HOSE LP 1/2" TOTAL INCHES FROM CHART BELOW
	" НО-14	HOSE HP CRIMP 1/2" TOTAL INCHES FROM CHART BELOW
		^~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~
1	HO-2 (A)	"
1	HO-2 (A)	
1	но-2	FA-13 FA-13 FA-13 FA-13 TO OP HELM CONTROL
1	HO-2 B HO-13 C	LO OR HELM
1 1 1	HO-13 C HO-13 D	" LO OR HELM CONTROL HELM FA-13 FA-13
1 1 1 1	HO-2 B HO-13 C HO-13 D HO-5 E	" " " " " " " " " " " " "
1 1 1	HO-13 C HO-13 D	" " " " " " " " " " " " "
1 1 1 1	HO-2 B HO-13 C HO-13 D HO-5 E	" " " " " " " " " " " " "
1 1 1 1 1	HO-2 B HO-13 C HO-13 D HO-5 E HO-14 F	" HELM FA-13 FA-13 " POST " " " " " " " " " " " " " " " " " "
1 1 1 1 1	HO-2 B HO-13 C HO-13 D HO-5 E HO-14 F	" HELM FA-13 FA-13 " POST " PT-30 " TO OP CONTROL FA-13 FA-13 FA-13 FA-13
1 1 1 1 1	HO-2 B HO-13 C HO-13 D HO-5 E HO-14 F	" HELM FA-13 FA-13 " POST " FOR OIL TANK HOSE AND FITTINGS REFER TO OIL TANKS TO OP CONTROL HELM FA-13 FA-13 FA-13 PT-30 B C D
1 1 1 1 1	HO-2 B HO-13 C HO-13 D HO-5 E HO-14 F	" HELM FA-13 FA-13 " POST " " " " " " " " " " " " " " " " " "
1 1 1 1 1	HO-2 B HO-13 C HO-13 D HO-5 E HO-14 F	" HELM FA-13 FA-13 " POST " " PT-13 FOR OIL TANK HOSE AND FITTINGS REFER TO OIL TANKS TO OP CONTROL HELM TO OP CONTROL A PT-13 B C D