



ATWOOD-HAMLIN  
MANUFACTURING CO., INC.  
Since 1949

# HOW TO...

## Measure for Pew Seat Cushions



Start by measuring, along the back of the pew seat, the length from end to end within the arm rests.<sup>①</sup> Then measure the depth of the seat from the very front edge to the back.<sup>②</sup> Also, as seen in the inset illustration, measure the thickness of the seat at the front edge.<sup>③</sup>

If needing cushions for the backs of pews, measure from the bottom, where it meets the seat, up to the top rail.<sup>④</sup>

Along with the measurements, please send photographs detailing these areas so that we can familiarize ourselves with your particular pews, and possible applications.

**\*\*ATTENTION: On measurement #2, if you are measuring for our regular pew form cushions, measure from the back of the seat forward to just before the seat starts to curve down. However, for our drop-front cushions, measure from the back of the seat forward to the furthest most edge of the seat.**