

- 1 Disconnect the power adapter.
- 2 look for the little orange square with black keyboard icon (KeyScan NoTouch icon) - at the bottom left on the computer by the clock
- 3 right click on it and left click on "disable no touch AutoScan"
- 4 if the icon is still there right click on it again and left click "exit"
- 5 go to control panel (start-> control panel)
- 6 click "add and remove programs" and wait till window is fully "populated"
- 7 left click on KS-V0... and click remove
- 8 Follow uninstall directions.
- 9 If computer asks to reboot please do so.
- 10 go back to control panel
- 11 click "add and remove programs" and wait till window is fully "populated"
- 12 check if you find "windows driver for KeyScan image" if not skip to step 15
- 13 left click on "windows driver for KeyScan image" and click remove
- 14 Follow uninstall directions.
- 15 Reboot your computer.
- 16 go to my computer - go to C:\ check if "KeyScan" or "KS810" or "KS810-P" folder is still there if yes - delete the folder
- 17 go to my computer - go to C:\program files\ and check if KeyScan folder is still there if yes - delete the folder
go to my computer - go to C:\Documents and Settings\All Users\Application Data\ and check if KeyScan folder is still there if yes - delete the folder
- 19 Delete those folders permanently out of the recycle bin.