

Project Name: _	
Date:	_ Note:















Application: family room, bedroom, hallway, corridor, or any other common area in your living space.

Feature


- · The ultra slim LED downlights/surface mini panel comes with separate steel encased LED driver with watertight seal
- Backlit technology gives more even and brighter light distribution
- Airtight & Type IC Rated: No housing Required
- Snap-in mounting springs and easy wiring access for fast & easy Installation: Save labor cost.
- Junction Box Included: No additional hardware required.
- Damp location rated and dimmable with approved dimmers
- Body: Durable, die cast aluminum alloy for optimal heat dissipation
- White, Nickel or Black for choice--Scratch resistant and smooth finish


Specifications HY-SDL-R3-6W-HY-SDL-R4-9W-HY-SDL-S4-9W-HY-SDL-R6-12W-HY-SDL-S6-12W-5CCT HY-SDL-R8-18W-Model 5CCT 5CCT 5CCT 5CCT 5CCT Size 3" Round 4" Round 4" Square 6" Round 6" Square 8" Round Power 6W 9W 12W 18W Input Voltage 120V AC 60Hz 50Hz/60Hz Frequency Dimming Triac dimmable 0-10V Dimmable 80LM/W 85LM/W Lumen Beam Angle 120° 5CCT (2700K/3000K/3500K/4000K/5000K) Tunable CCT CRI >80 Lumen Maintenance over 70% @ 360000+ Hours Working Life Oper. -4°F to 104°F (-20°C) to 40°C) Temperature Certification ETL/Energy Star




Project Name: _	
Date:	Note:

DIMENSION





PHOTOMETRIC REPORT





Project Name: _	
Date:	Note:

PACKAGE INFO						
Model	HY-SDL-R3-6W- 5CCT	HY-SDL-R4-9W- 5CCT	HY-SDL-S4-9W-5CCT	HY-SDL-R6-12W- 5CCT	HY-SDL-S6-12W- 5CCT	HY-SDL-R8-18W- 5CCT
Size	3" Round	4" Round	4" Square	6" Round	6" Square	8" Round
Qty/Pack	20 PCS			10 PCS		
	395X265X240mm	395X315X290mm	395X315X290mm	395X415X400mm	395X385X370mm	520X400X260mm
Package Size	15.55"X10.4"X9.4"	15.55"X12.4"X11.4"	15.55"X12.4"X11.4"	15.6"X16.3"X15.7"	15.6"X15.1"X14.57"	20.47"X15.8"X10.2"
Package Weight	6.5 kg/14.3 lbs	7.3 kg/16.1 lbs	7.4 kg/16.3 lbs	9.5 kg/21 lbs	9.3 kg/20.5 lbs	6.4 kg/14.11 lbs
Package CBM	0.025122	0.036083	0.036083	0.06557	0.056268	0.05408
40GP Capacity	~46170 PCS	~32140 PCS	~32140 PCS	~17690 PCS	~20610 PCS	~10720 PCS
40HQ Capacity	~54130 PCS	~32140 PCS	~37690 PCS	~20740 PCS	~24170 PCS	~12570 PCS
45HQ Capacity	~62090 PCS	~32140 PCS	~43230 PCS	~23790 PCS	~27720 PCS	~14420 PCS

ORDERIN CODE DEFINITION

Company Code	Product	Shape Size		Watt	ССТ
SDL: HY Ultra-Slim Downlight	R3: Round 3"		6W		
		R4: Round 4"	S4: Square 4"	9W	5CCT:
	R6: Round 6"	S6: Square 6"	12W	2700K/3000K/3500 K/4000K/5000K	
		R8: Round 8		18W	

INSTALLATION PROCEDURE



WARNING:

- 1.Switch off before installation.
- 2. Switch on only after complete installation and examination of the circuit.









Project Name: _	
Date:	Note:


WIRING GUIDE

- Open the hardwire box swing cover and remove one of the knock out holes on the side of the electrical box, based on the installation position.
- 2. Feed the wires from the electrical source through the open knock out hole in the electrical box
- Connect black wire to live wire, white wire toneutral wire, and green wire with ground (as shown) and secure using wago connector. Close the cover of the box.



Select color and move the CCT switch.you can change the color temperature to:2700k/3000k/3500k/4000k/5000k by the CCT switch(If CCT selectable applicable)





INSTALLATION INSTRUCTION

Installation Preparation

- Locate a suitable position to plate the fixture and open in accordance to the cut-hole dimensions (refer to Hole Cut Table for appropriate size).
- Run electrical wire from the switch(power supply) through the mounting hole- use NMD90 Romex or BX cable.

Ceiling Hole Cut Size 3" Round DOWNLIGHT: ф3.15"(80mm) 4" Round DOWNLIGHT: ф4.33"(110mm) 6" Round DOWNLIGHT: ф6.29"/(160mm) 8" Round DOWNLIGHT: ф8.15"/(207mm) 4" Square DOWNLIGHT: 3.94"X3.94" (100X100mm) 6" Square DOWNLIGHT: 5.51"X5.51" (140X140mm)

Fixture Installation

- 1. Positioning the electrical box: Holding the clips, and push the fixture thru the cut-out hole in the ceiling and position it where desired.
- Connecting the electrical box to the LED Downlight: Connect the remote driver box to the light fixture and Twist the two parts of the connector in opposite directions to lock them together.
- Push the spring clip on the fixture upward and push the fixture through the ceiling hole and place fixture in the hole. Release the clips and the fixture will be pulled flush to the ceiling, making sure the spring clips are holding securely
- 4. Turn on the power and make sure your fixture is working properly. If the fixture is not lighten up in 5 seconds, turn power off, carefully remove the module and double check all wiring and replace.

