

How to Read ECM and Save Tune Using VCM Editor


This guide provides a straightforward walkthrough for capturing vehicle information and saving it to your computer using the VCM Editor software. Follow these steps to ensure your vehicle data is read accurately and stored correctly for future diagnostics.

Launch VCM Editor


1 Open Windows Search




2 Open VCM Editor




3 Click File



4 Click Close




5 Click Green Up Arrow to open tune file reader




Read Vehicle Data

6 Make Sure ENGINE IS OFF and KEY IS IN RUN POSITION, Click Gather Info




7 Click Read




8

Some ECM's give a virtual read, some ECMs will read out. Once it is complete reading, Click OK




Save the Tune File


9 Click Save As



10 Select the File name field save tune file read.



11 Click Save



12 Click Close

