


## Updating Earthworks and Display


From the Display open the main menu then open Webui




Enter admin and password Sitech#!




Open Monitor




Open Onboard Devices and then unlock




Install USB drive with Update file and Touch Add Firmware




Navigate to Firmware file .SG6 and Open



Firmware will upload to EC520 from the USB



After upload is complete Touch System ECM drop down and then firmware.




Select desired Firmware and then Apply firmware

Wait for system to complete update. System will restart and go to main Android screen


After update open operator app and more updates may need to be installed automatically like machine control plugin, follow instructions on screen.

To update Display insert USB drive with the display firmware in a zip folder on root of usb

Press and hold power button. Select upgrade from USB




Select correct zip file for your display(510, 520, or 540) and select update.







Display will start update process.



Then Select OK



Display will start Updating




Wait for display to complete update. System will restart after update is complete







When display is done updating the main screen will appear,




Swipe up and go to settings gear cog



In settings go to bottom of page and click on about tablet



Under about check build number the newest build on 510 a and 520 displays is V4.31.2





THE GNSS GUILD