

Sam4s ER-900 Series Guide:

Past Item Void: Preset Priced Item that was rung in early in the current transaction.

- Press [VOID]
- Press an item [sandwich / chicken / etc.]
- Continue transaction as normal

Past Item Void: Open Priced Item that was rung in early in the current transaction.

- Press [VOID]
- Enter dollar amount
- Press an item [extra / dessert]
- Continue transaction as normal

Current Item Void: Item that was just rung in.

- Press [ERROR CORR]
- Continue transaction as normal

Refund: Preset Price Item → After money has been exchange.

- Press [RETURN]
- Press an item [sandwich / chicken / etc.]
- Continue transaction as normal

Refund: Open Price Item → After money has been exchange.

- Press [RETURN]
- Enter dollar amount
- Press an item [extra / dessert.]
- Continue transaction as normal

Cancel: Cancel out the ACTIVE transaction.

- Press [CANCEL]