

Merchandise Return (Refund) - SPS 500 Series

Merchandise Return with Open Keys on Keyboard (Refund)

1. Press **MDSE RTRN** button
2. Enter in Dollar Amount BEFORE TAX
3. Press Misc (or Misc Tax, etc.)
4. Press **CASH** (or Credit Card, etc)

Merchandise Return with Open Keys on Keyboard with Tax Shift (Refund)

1. Press **MDSE RTRN** button
2. Press TAX SHIFT
3. Enter in Dollar Amount
4. Press Misc (or Misc Tax, etc.)
5. Press **CASH** (or Credit Card, etc)

Merchandise Return with Open Keys using PLU #'s (Refund)

1. Press **MDSE RTRN** button
2. Press **PLU #**
3. Enter the # of the PLU needed to refund
4. Enter in Dollar Amount (Press OK on Amount)
5. Press **CASH** (or Credit Card, etc)