




Tri-Sport


REPLACEMENT PARTS LIST
RTS-5, RTS-8, & RTS-MAC

ALSPORT, INCORPORATED


84 Whittlesey, Norwalk, Ohio 44857 •




Item No.	Part No.	Quan't. No.	Description
1	733-195	1	Weld Assembly Frame
2	733-203	1	Torque Converter Shield (Mac)
3	733-202	1	Torque Converter Shield (5 & 8)
4	726-194	1	Torque Converter Shield Mt'g. Strap (Mac)
5	726-193	1	Torque Converter Shield Mt'g. Strap (5 & 8)
6	710-121	3	Hex Hd. Bolts 1/4-20 x 3/4"
7	736-104	3	Flat Washers 5/16"
8	712-102	3	Locknuts 5/16-24
9	733-196	1	Leading Link Fork
10	733-197	1	Lower Loop Leading Link
11	749-114	2	Front Shocks
12	710-116	6	Hex Hd. Bolts 3/8-24 x 1-3/4"
13	712-135	6	Locknuts 3/8-24
14	750-107	2	Fork Bushings
15	736-102	2	Flat Washers 3/8 U.S.S.
16	760-163	1	Leading Link Fork Complete
17	741-106	2	Fork Bearings
18	733-198	2	Torque Arm
19	723-112	1	Fuel Line 16 5/8" (Mac)
20	723-112	1	Fuel Line 8 3/4" (8)
21	710-168	4	Hex Hd. Bolts 1/4-20 x 3/4"
22	736-116	4	Flat Washers 1/4"
23	712-129	4	Locknuts 1/4-20
24	723-111	1	In Line Fuel Filter
	723-110	1	Fuel Line Fitting 90°
	737-102	1	Gas Tank Plug
	723-154	1	Gas Tank (8 & Mac)



Item No.	Part No.	Quan't. No.	Description	Item No.	Part No.	Quan't. No.	Description
25	752-114	1	Tecumseh 8 HP Engine	53	710-176	4	Socket Hd. Screws 1/4-20 x 1 1/4"
26	717-120	1	Torque Converter - Driver (8)	54	710-128	4	Hex Hd. Bolts 5/16-24 x 1"
27	717-121	1	Torque Converter - Driven (8)	55	736-104	4	Flat Washers 5/16 ID x 11/16 OD
28	714-108	1	Key 1/4 59 x 3-3/4"	56	712-102	4	Locknuts 5/16-24
29	750-121	1	Driver - Spacer	57	754-105	1	Belt (Mac)
30	710-178	1	Torque Bolt 3/8-24 x 3-1/2"	58	750-127	1	Crankshaft Converter Adaptor
31	736-106	2	Snubbing Washers	59	718-108	1	Expansion Chamber (Mac)
32	736-102	1	Flat Washer 3/8"	60	718-107	1	Muffler (Mac)
33	736-101	1	Lock Washer 3/8"	61	721-101	1	Exhaust Gasket (Mac)
34	754-103	1	Belt (8)	62	710-185	2	Exhaust Mt'g. Bolts 8-32 x 3/4"
35	752-115	1	Briggs & Straton 5 HP Engine	63	710-186	1	Expansion Chamber Bolt 3/8-24 x 4 7/8"
36	717-103	1	Torque Converter - Driver (5)	64	712-135	1	Hex Center Locknut 3/8-24
37	717-104	1	Torque Converter - Driven (5)	65	735-102	1	Rubber Grommet
38	710-110	1	Hex Hd. Bolt 5/16-24 x 1 3/4"	66	726-214	1	Expansion Chamber Mt'g. Bracket (MAC)
39	736-105	1	Lock Washer 5/16"	67	710-166	1	Hex Hd. Bolt 3/8-24 x 1"
40	736-104	1	Flat Washer 5/16"	68	712-135	1	Hex Locknut 3/8-24
41	750-101	1	Driver - Spacer	69	718-112	1	Reducing Tube (Mac)
42	754-106	1	Belt (5)	70	718-111	1	Flex Tube (Mac)
43	752-109	1	McCulloch 101 Engine	71	718-113	1	Exhaust Elbow (Mac)
44	733-205	1	Engine Mt'g Plate	72	732-111	2	Exhaust Springs (Mac)
45	723-166	1	Standard Carburetor BDC-14	73	726-231	1	Air Cleaner Rear Mt'g. Plate (Mac)
46	710-183	1	Mac Torque Bolt 3/8-24 x 1 1/2"	74	723-155	1	Air Cleaner Element Assy. (Mac)
47	714-110	1	Key 5/32 59 x 2 1/4"	75	726-230	1	Front Mt'g. Plate (Mac)
48	736-142	1	Flat Washer 1 1/2 OD x 3/4 ID	76	712-101	3	Hex Nuts 1/4-20
49	717-117	1	Torque Converter - Driver RTS-Mac	77	750-137	3	Air Cleaner Plate Spacers (Mac)
50	750-119	1	Spacer Driven Torque	78	710-184	3	Fastening Rods 1/4-20 x 3 3/4" (Mac)
51	717-118	1	Torque Converter - Driven (Mac)	79	736-143	3	Flat Washers (Mac)
52	746-112	1	Throttle Cable Bracket	80	723-131	1	Air Cleaner Gasket



Item No.	Part No.	Quan't. No.	Description	Item No.	Part No.	Quan't. No.	Description
81	719-106	1	Alum. Ltd. Slip Housing	96	741-103	2	Diff. Bearings w/Collars
82	719-105	1	Alum. Ltd. Slip Housing - Sprocket Side	97	749-116	4	1" Bearing Flanges
83	748-120	1	HA 252 Sprocket 54T	98	710-128	6	Hex Hd. Bolts 3/16-24 x 1"
84	738-105	2	Inner Axles HA 252	99	712-106	6	Hex Center Locknuts 3/16-24
85	717-123	1	Ltd. Slip diff. w/sprocket HA 252	100	717-114	2	Universal Joints
	710-179	4	Hex Hd. Bolts 5/16-18 x 4"	101	710-158	4	Set Screws 3/8-16 x 3/4"
	712-110	4	Hex Locknuts 5/16-18	102	713-112	1	No. 40 Drive Chain
	736-135	12	Flatwashers 7/8 OD x 1/2 ID	103	713-110	1	No. 40 Master Link LL
	736-137	2	Flatwashers 1 3/8 OD x 7/8 ID	104	712-135	1	Hex Locknut 3/8-24
	711-124	4	Carrier Pins HA 252	105	736-138	1	Internal Lockwasher
	748-125	4	Carrier Gears HA 252	106	736-102	2	Flatwashers 3/8"
	748-126	2	Axle Gears HA 252	107	710-102	1	Hex Hd. Bolt 3/8-24 x 2"
	732-110	4	Carrier Springs HA 252	108	751-117	1	Chain Tightener
	716-104	2	Axle Snap Rings	109	733-199	1	RH Brake Anchor
	737-101	1	Grease Fitting	110	733-194	1	LH Brake Anchor
86	717-113	2	Outer Axles	111	757-105	2	1" Brake Drums w/Set Screw
87	733-140	2	Wheel Hubs	112	757-100	2	Brake Bands
88	736-126	2	Flat Washers 5/8 SAE	113	757-104	2	Brake Pins w/Set Screw
89	712-114	2	Hex Locknuts 5/8-18	114	732-100	2	Brake Springs
90	714-102	2	Keys 3/16 Sq. x 2"	115	711-123	1	Jackshaft
91	733-200	1	RH Axle Support	116	741-100	2	Bearings 5/8 Bore
92	733-201	1	LH Axle Support	117	750-122	2	Lock Collars 5/8 Bore
93	714-106	2	Keys 1/4 Sq. x 1 1/8"	118	748-124	1	Sprocket (Replaces 748-111)
94	714-109	2	Keys 1/4 Sq. x 1 3/4"	119	714-104	1	Key 3/16 Sq. x 1"
95	741-105	4	Axle Support Bearings				



Item No.	Part No.	Quan't. No.	Description
120	751-107	1	Bolt Bushing for Shock
121	723-140	1	RTS Seat Pad
122	723-165	1	RTS Seat Pad Front Protector
123	720-111	1	Handle Bar
124	734-118	2	Rear Tire Assy.
125	734-116	1	Front Tire Assy.
126	759-124	1 pr.	"RTS" Decal
127	759-120	1 pr.	"Tri-Sport" Decal
128	746-134	2	Brake Cables
129	746-102	1	Throttle Cable
130	720-101	1	Throttle & Dummy Grip
130A	720-113	1	Dummy Grip
131	746-104	1	LH Brake Lever
132	746-100	1	RH Brake Lever
133	725-172	1	Kill Wire Assy. (Mac)
	725-173	1	Kill Wire Assy. (8)
	725-174	1	Kill Wire Assy. (5)
	725-138	1	Kill Switch
134	710-133	2	Hex Hd. Bolts 1/4-20 x 2"
135	710-103	2	Carriage Hd. Bolts 1/4-20 x 2"
136	736-116	2	Flatwashers 1/4"
137	736-106	2	Snubbing Washers
138	735-100	2	Rubber Grommets
139	736-103	4	Lockwashers 1/4"
140	712-101	4	Hex Nuts 1/4-20

