

Frequency Divider P/n 411.088


p/n FA100

Fitting Instructions

This device is designed to convert and/or buffer a sine-wave signal into a square-wave, it can divide the signal by 1, 2, 4, 8, 16, 32, 64, 128 by changing the internal switch position accordingly.

The internal switch sequence, factory setting is Switch 3 "On" all the rest "Off", which is set to divide by four:

Sw #	1	2	3	4	5	6	7	8
On			o					
Off	o	o		o	o	o	o	o



For further information contact: SiemensVDO, 115 Northern Rd Heidelberg Heights Vic 3081
Ph (03) 9450 3254 Fax (03) 9450 3110

FA 15/05/01