



No.	PART No.	PART NAME	PRICE	No.	PART No.	PART NAME	PRICE
101	2040103-05010-9	COUNTER SUNK SCREW		301	11230-0863601-1	GUN BODY UNIT	
102	11381-0954702-1	WASHER		302	2041101-05020-0	O-RING	
103	1135G-0460001-1	RUBBER PAD		303	11346-0864301-1	END CAP	
104	11371-0954701-1	DEFLECTOR		304	1132L-0014701-1	DUSTY COVER	
105	2041102-05050-0	O-RING		305	1135V-0000007-1	AIR PLUG	
106	1135S-0350001-1	GROMMET		401	2041108-06060-0	O-RING	
107	11369-0974301-1	CAP		402	2041108-01010-0	O-RING	
108	2040104-03010-0	HEX.SOC.HD.SCREW		403	11382-0974701-1	NOSE PIECE	
109	2040100-04030-0	BOLT ASSY		404	2040101-05040-2	HEX.SOC.HD.BOLT	
110	11302-0864701-1	CYLINDER CAP SEAL		405	2041100-01090-0	O-RING	
111	11381-0970001-1	WASHER SEAL		406	11364-0974702-1	FEED PISTON-B	
112	11370-0970001-1	SEAL		407	2041104-03040-0	O-RING	
113	11360-0354701-3	COMPRESSION SPRING		408	1134W-0970001-1	FEED BUMPER	
114	11381-0864701-1	WASHER		409	2040100-04080-2	BOLT ASSY	
115	2041108-05070-0	O-RING		410	11367-0970001-1	PUSHER SPRING	
116	11368-0970001-2	HD.VALVE PISTON		411	11366-0974701-1	FEED PISTON CAP	
117	2041108-06050-0	O-RING		412	2040300-08010-0	C-RING	
118	2041108-05060-0	O-RING		413	2040101-04131-0	HEX.SOC.HD.BOLT	
119	11204-0970001-2	DRIVER UNIT		414	11310-0864701-1	DOOR LATCH	
120	11399-0860001-1	COLLAR		415	11311-0974701-1	LATCH SPRING	
121	11320-0970001-1	CYLINDER		416	11361-0974701-1	DOOR	
122	2041108-06010-0	O-RING		417	1135H-0860001-1	PU RETAINER	
123	11321-0860001-1	CYLINDER SPACER		418	204040005060-0	SPRING PIN	
124	2041101-09020-0	O-RING		419	1133C-0970001-1	STOPPER FINGER SPRING	
125	2041100-06010-0	O-RING		420	11358-0864701-1	NAIL STOP	
126	11327-0864701-1	BUMPER-A		421	11359-0864701-1	PIN-NAIL STOP	
127	11327-0864702-1	BUMPER-B		422	11330-0974702-1	SAFETY	
128	1135S-0860001-1	GROMMET A		423	11337-0864701-1	SAFETY SPRING	
129	11362-0864701-1	DOOR SHAFT PIN		424	11338-0864701-1	SAFETY GUIDE	
130	11397-0864701-1	GUIDE COVER		425	11354-0974701-1	MAGAZINE CASE	
201	2041104-02060-0	O-RING		426	11357-0954701-1	MAGAEING POST	
202	11374-0860001-1	PLUNGER CAP		427	1138Y-0954701-2	RUBBER RING	
203	2041100-02050-0	O-RING		428	1134M-0864701-1	SPRING BASE	
204	2041100-01070-0	O-RING		429	11356-0970001-1	SPACER	
205	1133S-0860001-1	VALVE PLUNGER		430	1138W-0860001-1	SPACER	
206	2041100-01030-0	O-RING		431	11328-0970001-1	PULL SPRING	
207	11376-0860001-1	SPING		432	11355-0974701-2	MAGAZINE COVER	
208	2041108-01020-0	O-RING		433	11365-0864701-1	PIN FEED PISTON	
209	11375-0860002-1	PLUNGER		434	11306-0974701-1	FEED FINGER	
210	11373-0860001-1	TRIGGER VALVE HEAD		435	11364-0974701-1	FEED PISTON-A	
211	11329-0860001-1	PIN		436	11307-0970001-1	FEED FINGER SPRING	
212	1137A-0860001-1	COVER-PLUNGER		437	2040101-04121-0	HEX.SOC.HD.BOLT	
213	2041104-02070-0	O-RING		438	1134R-0974701-1	SPRING COVER	
214	2041100-01050-0	O-RING		439	2040501-04010-0	BOLT CAP	
215	2040401-05100-0	SPIRAL PINS		440	1136R-0864701-1	MAGAZINE SHAFT PIN	
216	11317-0864701-1	SECONDARY TRIGGER					
217	11316-0864701-2	TRIGGER					
218	2040400-05080-0	SPRING PIN					
219	2040401-05120-0	SPIRAL PINS					