






FEATURING QUALITY YOU CAN SEE




White



Sharp Grey



Navy Blue



Charcoal Black

Table of Contents


Base Cabinets	1
Wall Cabinets	5
Tall Cabinets	9
Accessories	10
Vanity Cabinets	11
Accessories	13

BASE CABINET

1 DOOR / 1 DRAWER

Model	Description	W*H*D
B09-SG/SW	BASE CABINET 9" SHAKER	9**34-1/2**24"
B12-SG/SW/NB/BK	BASE CABINET 12" SHAKER	12**34-1/2**24"
B15-SG/SW/NB/BK	BASE CABINET 15" SHAKER	15**34-1/2**24"
B18-SG/SW/NB/BK	BASE CABINET 18" SHAKER	18**34-1/2**24"
B21-SG/SW/NB/BK	BASE CABINET 21" SHAKER	21**34-1/2**24"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.




BASE CABINET

SINK BASE

Model	Description	W*H*D
SB30-SG/SW/NB/BK	SINK BASE CABINET 30" SHAKER	30**34-1/2**24"
SB33-SG/SW/NB/BK	SINK BASE CABINET 33" SHAKER	33**34-1/2**24"
SB36-SG/SW/NB/BK	SINK BASE CABINET 36" SHAKER	36**34-1/2**24"
SB39-SG/SW/NB/BK	SINK BASE CABINET 39" SHAKER	39**34-1/2**24"
SB42-SG/SW/NB/BK	SINK BASE CABINET 42" SHAKER	42**34-1/2**24"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.




BASE CABINET

2 DOORS / 1 DRAWER

Model	Description	W*H*D
B24-SG/SW/NB/BK	BASE CABINET 24" SHAKER	24**34-1/2**24"
B27-SG/SW/NB/BK	BASE CABINET 27" SHAKER	27**34-1/2**24"
B30-SG/SW/NB/BK	BASE CABINET 30" SHAKER	30**34-1/2**24"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.




BASE CABINET

2 DOORS

Model	Description	W*H*D	W1
FSB33-SG/SW/NB/BK	FARMERS SINK BASE CABINET 33"	33**34-1/2**24"	27"
FSB36-SG/SW/NB/BK	FARMERS SINK BASE CABINET 36"	36**34-1/2**24"	30"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.




BASE CABINET

2 DOORS / 2 DRAWERS

Model	Description	W*H*D
B33-SG/SW/NB/BK	BASE CABINET 33" SHAKER	33**34-1/2**24"
B36-SG/SW/NB/BK	BASE CABINET 36" SHAKER	36**34-1/2**24"
B39-SG/SW/NB/BK	BASE CABINET 39" SHAKER	39**34-1/2**24"
B42-SG/SW/NB/BK	BASE CABINET 42" SHAKER	42**34-1/2**24"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.




BASE CABINET

1 DRAWER

Model	Description	W*H*D
MB27-SG/SW/NB/BK	MICROWAVE BASE CABINET 27"	27**34-1/2**24"
MB30-SG/SW/NB/BK	MICROWAVE BASE CABINET 30"	30**34-1/2**24"


* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.



BASE CABINET

3 DRAWERS

Model	Description	W*H*D
DB12-SG/SW/NB/BK	DRAW BANK W/3 DRAWS 12" SHAKER	12**34-1/2**24"
DB15-SG/SW/NB/BK	DRAW BANK W/3 DRAWS 15" SHAKER	15**34-1/2**24"
DB18-SG/SW/NB/BK	DRAW BANK W/3 DRAWS 18" SHAKER	18**34-1/2**24"
DB21-SG/SW/NB/BK	DRAW BANK W/3 DRAWS 21" SHAKER	21**34-1/2**24"
DB24-SG/SW/NB/BK	DRAW BANK W/3 DRAWS 24" SHAKER	24**34-1/2**24"
DB27-SG/SW/NB/BK	DRAW BANK W/3 DRAWS 27" SHAKER	27**34-1/2**24"
DB30-SG/SW/NB/BK	DRAW BANK W/3 DRAWS 30" SHAKER	30**34-1/2**24"
DB33-SG/SW/NB/BK	DRAW BANK W/ 3 DRAWS 33" SHAKER	33**34-1/2**24"
DB36-SG/SW/NB/BK	DRAW BANK W/ 3 DRAWS 36" SHAKER	36**34-1/2**24"




* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.

BASE CABINET

POT & PAN DRAWER

Model	Description	W*H*D
DBP18-SG/SW/NB/BK	POT and PAN DRAWER CABINET 18"	18**34-1/2**24"
DBP21-SG/SW/NB/BK	POT and PAN DRAWER CABINET 21"	21**34-1/2**24"
DBP24-SG/SW/NB/BK	POT and PAN DRAWER CABINET 24"	24**34-1/2**24"
DBP36-SG/SW/NB/BK	POT and PAN DRAWER CABINET 36"	36**34-1/2**24"



* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.


BASE CABINET

BLIND CORNER

Model	Description	W*H*D
BBC42-SG/SW	BASE BLIND CABINET 42" SHAKER	42**34-1/2**24"

* SG--Sharp Grey, SW--White.

Reversible for Left & Right Applications.
For 45" Spaces.
Door/Drawer Front Width 17-1/2".




BASE CABINET

SPICE RACK

Model	Description	W*H*D
BSR09-SG/SW/NB/BK	BASE 9 CABINET W/PULL OUT SPICE RACK SHAKER	9**34-1/2**24"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.




BASE WASTE CABINET

TRASH PULL OUT

Model	Description	W*H*D
BWB18-SG/SW/NB/BK	BASE WASTE BASKET 18" SHAKER	18**34-1/2**24"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.




BASE CABINET

LAZY SUSAN

Model	Description	W*H*D
LS33-SG/G	BASE LAZY SUSAN 33" SHAKER	33**34-1/2**24"
LS36-SG/G	BASE LAZY SUSAN 36" SHAKER	36**34-1/2**24"


* SG--Shaker Grey, G--White.



WALL CABINET

1 Door 30"36"42"

Model	Description	W*H*D
W0930-SG/SW	WALL CABINET 9W 30H SHAKER	9**30**12"
W1230-SG/SW	WALL CABINET 12W 30H SHAKER	12**30**12"
W1530-SG/SW	WALL CABINET 15W 30H SHAKER	15**30**12"
W1830-SG/SW	WALL CABINET 18W 30H SHAKER	18**30**12"
W2130-SG/SW	WALL CABINET 21W 30H SHAKER	21**30**12"
W0936-SG/SW	WALL CABINET 9W 36H SHAKER	9**36**12"
W1236-SG/SW	WALL CABINET 12W 36H SHAKER	12**36**12"
W1536-SG/SW	WALL CABINET 15W 36H SHAKER	15**36**12"
W1836-SG/SW	WALL CABINET 18W 36H SHAKER	18**36**12"
W2136-SG/SW	WALL CABINET 21W 36H SHAKER	21**36**12"
W0942-SG/SW	WALL CABINET 9W 42H SHAKER	9**42**12"
W1242-SG/SW	WALL CABINET 12W 42H SHAKER	12**42**12"
W1542-SG/SW	WALL CABINET 15W 42H SHAKER	15**42**12"
W1842-SG/SW	WALL CABINET 18W 42H SHAKER	18**42**12"
W2142-SG/SW	WALL CABINET 21W 42H SHAKER	21**42**12"



* SG--Sharp Grey, SW--White.


WALL CABINET

2 Doors 30"36"42"

Model	Description	W*H*D
W2430-SG/SW	WALL CABINET 24W 30H SHAKER	24**30**12"
W2730-SG/SW	WALL CABINET 27W 30H SHAKER	27**30**12"
W3030-SG/SW	WALL CABINET 30W 30H SHAKER	30**30**12"
W3330-SG/SW	WALL CABINET 33W 30H SHAKER	33**30**12"
W3630-SG/SW	WALL CABINET 36W 30H SHAKER	36**30**12"
W3930-SG/SW	WALL CABINET 39W 30H SHAKER	39**30**12"
W4230-SG/SW	WALL CABINET 42W 30H SHAKER	42**30**12"
W2436-SG/SW	WALL CABINET 24W 36H SHAKER	24**36**12"
W2736-SG/SW	WALL CABINET 27W 36H SHAKER	27**36**12"
W3036-SG/SW	WALL CABINET 30W 36H SHAKER	30**36**12"
W3336-SG/SW	WALL CABINET 33W 36H SHAKER	33**36**12"

W3636-SG/SW	WALL CABINET 36W 36H SHAKER	36**36**12"
W3936-SG/SW	WALL CABINET 39W 36H SHAKER	39**36**12"
W4236-SG/SW	WALL CABINET 42W 36H SHAKER	42**36**12"
W2442-SG/SW	WALL CABINET 24W 42H SHAKER	24**42**12"
W2742-SG/SW	WALL CABINET 27W 42H SHAKER	27**42**12"
W3042-SG/SW	WALL CABINET 30W 42H SHAKER	30**42**12"
W3342-SG/SW	WALL CABINET 33W 42H SHAKER	33**42**12"
W3642-SG/SW	WALL CABINET 36W 42H SHAKER	36**42**12"
W3942-SG/SW	WALL CABINET 39W 42H SHAKER	39**42**12"
W4242-SG/SW	WALL CABINET 42W 42H SHAKER	42**42**12"

* SG--Sharp Grey, SW--White.




WALL CABINET

2 Doors 12"-24"

Model	Description	W*H*D
W3012-SG/SW	WALL CABINET 30W 12H SHAKER	30**12**12"
W3015-SG/SW	WALL CABINET 30W 15H SHAKER	30**15**12"
W3018-SG/SW	WALL CABINET 30W 18H SHAKER	30**18**12"
W3021-SG/SW	WALL CABINET 30W 21H SHAKER	30**21**12"
W3024-SG/SW	WALL CABINET 30W 24H SHAKER	30**24**12"
W3315-SG/SW	WALL CABINET 33W 15H SHAKER	33**15**12"
W3318-SG/SW	WALL CABINET 33W 18H SHAKER	33**18**12"
W3321-SG/SW	WALL CABINET 33W 21H SHAKER	33**21**12"
W3324-SG/SW	WALL CABINET 33W 24H SHAKER	33**24**12"
W3612-SG/SW	WALL CABINET 36W 12H SHAKER	36**12**12"
W3615-SG/SW	WALL CABINET 36W 15H SHAKER	36**15**12"

W3618-SG/SW	WALL CABINET 36W 18H SHAKER	36**18**12"
W3621-SG/SW	WALL CABINET 36W 21H SHAKER	36**21**12"
W3624-SG/SW	WALL CABINET 36W 24H SHAKER	36**24**12"
W3612-24-SG/SW	WALL CABINET 36W 12H 24DEEP SHAKER	36**12**24"
W3615-24-SG/SW	WALL CABINET 36W 15H 24DEEP SHAKER	36**15**24"
W3618-24-SG/SW	WALL CABINET 36W 18H 24 DEEP SHAKER	36**18**24"
W3621-24-SG/SW	WALL CABINET 36W 21H 24DEEP SHAKER	36**21**24"
W3624-24-SG/SW	WALL CABINET 36W 24H 24DEEP SHAKER	36**24**24"




* SG--Sharp Grey, SW--White.

WALL CABINET

DIAGONAL CORNER

Model	Description	W*H*D
WDC2430-SG/SW	WALL DIAGONAL CABINET 24W 30H SHAKER	24**30**12"
WDC2436-SG/SW	WALL DIAGONAL CABINET 24W 36H SHAKER	24**36**12"
WDC2442-SG/SW	WALL DIAGONAL CABINET 24W 42H SHAKER	24**42**12"

* SG--Sharp Grey, SW--White.




WALL CABINET

WINE RACK CABINET

Model	Description	W*H*D
W3024WR-SG/SW	WINE RACK 30" BY 24"	30**24**12"

* SG--Sharp Grey, SW--White.




WALL CABINET

STEMWARE/GLASS HOLDER

Model	Description	W*D
W3012GH-SG/SW	GLASS / STEM HOLDER	30**12"

* SG--Sharp Grey, SW--White.




WALL CABINET

2 DOORS

Model	Description	W*H*D
W2412GD-SG/SW	GLASS DOOR CABINET 24"	24**12**12"
W3012GD-SG/SW	GLASS DOOR CABINET 30"	30**12**12"
W3312GD-SG/SW	GLASS DOOR CABINET 33"	33**12**12"
W3612GD-SG/SW	GLASS DOOR CABINET 36"	36**12**12"

* SG--Sharp Grey, SW--White.




WALL CABINET

BLIND CORNER

Model	Description	W*H*D
WBC2730-SG/SW	WALL BLIND CORNER 27W 30H SHAKER	27**30**12"
WBC2736-SG/SW	WALL BLIND CORNER 27W 36H SHAKER	27**36**12"
WBC2742-SG/SW	WALL BLIND CORNER 27W 42H SHAKER	27**42**12"

Reversible for Left & Right Applications.
For 30" Spaces.
Door Width 12-3/4".

* SG--Sharp Grey, SW--White.




WALL CABINET

DIAGONAL END

Model	Description	W*H*D
WDEC30-SG/SW	WALL DIAGONAL END CABINET 30" SHAKER	12**30**12"
WDEC36-SG/SW	WALL DIAGONAL END CABINET 36" SHAKER	12**36**12"
WDEC42-SG/SW	WALL DIAGONAL END CABINET 42" SHAKER	12**42**12"

* SG--Sharp Grey, SW--White.



WALL CABINET

GLASS DOOR

Model	Description	W*H*D
W1530GD-SG/SW	WALL CABINET WITH GLASS DOOR 30" SHAKER	15**30**12"
W1536GD-SG/SW	WALL CABINET WITH GLASS DOOR 36" SHAKER	15**36**12"
W1542GD-SG/SW	WALL CABINET WITH GLASS DOOR 42" SHAKER	15**42**12"
W1830GD-SG/SW	WALL CABINET WITH GLASS DOOR 30" SHAKER	18**30**12"
W1836GD-SG/SW	WALL CABINET WITH GLASS DOOR 36" SHAKER	18**36**12"
W1842GD-SG/SW	WALL CABINET WITH GLASS DOOR 42" SHAKER	18**42**12"
W3030GD-SG/SW	WALL CABINET WITH GLASS DOOR 30" SHAKER	30**30**12"
W3036GD-SG/SW	WALL CABINET WITH GLASS DOOR 36" SHAKER	30**36**12"
W3042GD-SG/SW	WALL CABINET WITH GLASS DOOR 42" SHAKER	30**42**12"
W3630GD-SG/SW	WALL CABINET WITH GLASS DOOR 30" SHAKER	36**30**12"
W3636GD-SG/SW	WALL CABINET WITH GLASS DOOR 36" SHAKER	36**36**12"
W3642GD-SG/SW	WALL CABINET WITH GLASS DOOR 42" SHAKER	36**42**12"

Includes painted cabinet interior & shelves.


* SG--Sharp Grey, SW--White.



TALL CABINET **UTILITY**

Model	Description	W*H*D
UC1884-SG/SW	UTILITY CABINET 18W 84H SHAKER	18**84**24"
UC1890-SG/SW	UTILITY CABINET 18W 90H SHAKER	18**90**24"
UC1896-SG/SW	UTILITY CABINET 18W 96H SHAKER	18**96**24"
UC2484-SG/SW	UTILITY CABINET 24W 84H SHAKER	24**84**24"
UC2490-SG/SW	UTILITY CABINET 24W 90H SHAKER	24**90**24"
UC2496-SG/SW	UTILITY CABINET 24W 96H SHAKER	24**96**24"
UC3084-SG/SW	UTILITY CABINET 30W 84H SHAKER	30**84*24"
UC3090-SG/SW	UTILITY CABINET 30W 90H SHAKER	30**90*24"
UC3096-SG/SW	UTILITY CABINET 30W 96H SHAKER	30**96*24"


* SG--Sharp Grey, SW--White.



OVEN CABINET **DOUBLE OVEN**

Model	Description	W*H*D
OC3384-SG/SW	OVEN CABINET 33W 84H SHAKER	33**84**24"
OC3390-SG/SW	OVEN CABINET 33W 90H SHAKER	33**90**24"
OC3396-SG/SW	OVEN CABINET 33W 96H SHAKER	33**96**24"

* SG--Sharp Grey, SW--White.



ACCESSORIES **PULL OUT DRAWER**

Model	Description	W*H*D
POD18	PULL OUT DRAWER 18" UNDERNEATH	18**6**21"
POD24	PULL OUT DRAWER 24" UNDERNEATH	24**6**21"
POD30	PULL OUT DRAWER 30" UNDERNEATH	30**6**21"
POD36	PULL OUT DRAWER 36" UNDERNEATH	36**6**21"




ACCESSORIES **FALSE DOOR PANELS**

Model	Description	W*H
WFD30-SG/SW	WALL FALSE DOOR PANEL 12"W X 30"H SHAKER	12**30"
WFD36-SG/SW	WALL FALSE DOOR PANEL 12"W X 36"H SHAKER	12**36"
WFD42-SG/SW	WALL FALSE DOOR PANEL 12"W X 42"H SHAKER	12**42"
BFD-SG/SW/NB/BK	BASE FALSE DOOR PANEL 24"W X 30"H SHAKER	24**30"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.

Model	Description	W*H1	W*H2
UFD84-SG/SW	UTILITY FALSE DOOR PANELS	22-1/2**29-3/16"	22-1/2**49"
UFD90-SG/SW	UTILITY FALSE DOOR PANELS	22-1/2**35-1/8"	22-1/2**49"
UFD96-SG/SW	UTILITY FALSE DOOR PANELS	22-1/2**41-3/16"	22-1/2**49"

* SG--Sharp Grey, SW--White.




VANITY CABINET

3 DRAWERS

Model	Description	W*H*D
VDB12-SG/SW	VANITY DRAW BANK W/3 DRAW 12" SHAKER	12**34-1/2**21"
VDB15-SG/SW	VANITY DRAW BANK W/3 DRAW 15" SHAKER	15**34-1/2**21"
VDB18-SG/SW	VANITY DRAW BANK W/3 DRAW 18" SHAKER	18**34-1/2**21"
VDB21-SG/SW	VANITY DRAW BANK W/3 DRAW 21" SHAKER	21**34-1/2**21"

* SG--Sharp Grey, SW--White.




VANITY CABINET

KNEE DRAWER

Model	Description	W*H*D
VKD27-SG/SW	VANITY KNEE DRAWER 27" SHAKER	27**6**21"
VKD30-SG/SW	VANITY KNEE DRAWER 30" SHAKER	30**6**21"

* SG--Sharp Grey, SW--White.




VANITY CABINET

BASE CABINET

Model	Description	W*H*D
VBC12-SG/SW	VANITY BASE CABINET 12" SHAKER	12**34-1/2**21"
VBC15-SG/SW	VANITY BASE CABINET 15" SHAKER	15**34-1/2**21"
VBC18-SG/SW	VANITY BASE CABINET 18" SHAKER	18**34-1/2**21"
VBC21-SG/SW	VANITY BASE CABINET 21" SHAKER	21**34-1/2**21"
VBC24-SG/SW	VANITY BASE CABINET 24" SHAKER	24**34-1/2**21"
VBC27-SG/SW	VANITY BASE CABINET 27" SHAKER	27**34-1/2**21"
VBC30-SG/SW	VANITY BASE CABINET 30" SHAKER	30**34-1/2**21"

* SG--Sharp Grey, SW--White.




VANITY CABINET

SINK BASE

Model	Description	W*H*D
VSB24-SG/SW	VANITY SINK BASE 24" SHAKER	24**34-1/2**21"
VSB27-SG/SW	VANITY SINK BASE 27" SHAKER	27**34-1/2**21"
VSB30-SG/SW	VANITY SINK BASE 30" SHAKER	30**34-1/2**21"
VSB33-SG/SW	VANITY SINK BASE 33" SHAKER	33**34-1/2**21"
VSB36-SG/SW	VANITY SINK BASE 36" SHAKER	36**34-1/2**21"
VSB39-SG/SW	VANITY SINK BASE 39" SHAKER	39**34-1/2**21"
VSB42-SG/SW	VANITY SINK BASE 42" SHAKER	42**34-1/2**21"

* SG--Sharp Grey, SW--White.




VANITY CABINET


VANITY SINK BASE with DRAWERS

Model	Description	W*H*D	SINK	DRAWER
VSBD24-SG/SW	24" COMBINATION VANITY SINK BASE AND DRAWER BASE	24**34-1/2**21"	12"	12"
VSBD30-SG/SW	30" COMBINATION VANITY SINK BASE AND DRAWER BASE	30**34-1/2**21"	20"	10"
VSBD36-SG/SW	36" COMBINATION VANITY SINK BASE AND DRAWER BASE	36**34-1/2**21"	24"	12"
VSBD42-SG/SW	42" COMBINATION VANITY SINK BASE AND DRAWER BASE	42**34-1/2**21"	30"	12"
VSBD48-SG/SW	48" COMBINATION VANITY SINK BASE AND DRAWER BASE	48**34-1/2**21"	24"	12"
VSBD60-SG/SW	60" COMBINATION VANITY SINK BASE AND DRAWER BASE	60**34-1/2**21"	30"	15"


* SG--Sharp Grey, SW--White.



VSBD-24 / VSBD-30



VSBD-36 / VSBD-42



VSBD-48 / VSBD-60

ACCESSORIES **VENEER PANEL**

Model	Description	W*H
QVP3648-SG/SW	1/4" VENEER END PANEL 36"X48" SHAKER	36*48
QVP3696-SG/SW/NB/BK	1/4" VENEER PANEL 36"X96" SHAKER	36*96


* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.



ACCESSORIES **DW&REF END PANEL**

Model	Description	W*H*D
BEP3-SG/SW/NB/BK	BASE END PANEL 3" SHAKER	3**34-1/2**24"
REP396-SG/SW/NB/BK	REF END PANEL 3"X96" SHAKER	3**96**24"


* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.



ACCESSORIES **MOLDINGS**

Model	Description	Dimensions
CVM8-SG/SW	3" COVE CROWN MLDG 8' SHAKER	3-5/8**96"
SM8-SG/SW	3/4" SCRIBE MIDG 8' SHAKER	3/4**1/4**96"
OCM8-SG/SW	OUTSIDE CORNER MIDG 8' SHAKER	1**1**96"
QR8-SG/SW	QUARTER ROUND MLDG 8' SHAKER	3/4**3/4**96"
TLR8-SG/SW	1-3/4" LIGHT RAIL MIDG 8' SHAKER	1-3/4**3/4**96"
TK8-SG/SW/NB/BK	1/4" PLYWOOD TOE KICK 8' SHAKER	4-1/2**96**1/4"


* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.



ACCESSORIES **WOOD FILLER**

Model	Description	W*H
WF330-SG/SW/NB/BK	WOOD FILLER 3"X30" SHAKER	3**30"
WF342-SG/SW	WOOD FILLER 3"X42" SHAKER	3**42"
WF396-SG/SW/NB/BK	WOOD FILLER 3"X96" SHAKER	3**96"
WF630-SG/SW	WOOD FILLER 6"X30" SHAKER	6**30"
WF642-SG/SW	WOOD FILLER 6"X42" SHAKER	6**42"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.



ACCESSORIES **DOOR/DRAWER FRONT SAMPLE**

Model	Description	W*H
DFS-SG/SW/NB/BK	DOOR & DRAWER FRONT SAMPLE SHAKER	9**30"

* SG--Sharp Grey, SW--White, NB--Navy Blue, BK--Charcoal Black.

