

Student Saxophones

All Repairs are subject to technician approval

Level One Playing condition

- Re-Seat Pads as needed
 - Adjust springs as needed
 - Check/adjust Head-cork
 - Replace up to 2 pads
 - One additional Minor Repair
 - Align/Adjust/Oil/Regulate
 - Keywork
 - Play Test
- Soprano: By Estimate Only
Alto: \$85
Tenor: \$ 85
Baritone: *By Estimate only*
With C.O.A: \$50 additonal
Extra Charge For Additional Parts

Level Two Playing Condition

- All level one Playing Condition repairs
 - Replace two additional pads
 - 2 additional minor repairs
 - playtest
- Soprano: By Estimate Only
Alto: \$ 135
Tenor: \$150
Baritone: By Estimate only
With C.O.A: \$50 Additional

Clean, Oil, Adjust

- Recommended annual routine maintenance
 - Full disassembly, cleaning, and Oiling.
 - Basic key adjustment
 - Play test
- Extra Charge For Additional Parts*
Soprano Saxophone: \$125
Alto Saxophone: \$125
Tenor Saxophone: \$150
Baritone Saxophone: \$225
Extra Charge For Additional Parts

Re-pad Play Like New

- Replace all pads, corks, felts, and bumpers
 - Replace springs were needed.
 - Clean/oil/adjust all parts as appropriate.
 - Key fitting and tone hole leveling as appropriate
 - Up to 5 additional minor repairs
- Soprano Saxophone: \$475
Alto Saxophone: \$525
Tenor Saxophone: \$650
Baritone Saxophone: \$800
Heavily Damaged instrument/resurrection/vintage/pro horns: By Estimate only
Extra Charge For Additional Parts

Itemized repair

- Bent key
 - Broken Spring
 - Replace screw
 - Binding Keys
 - Solder work
- \$35 for the 1st
\$25 Each additional item
Extra Charge For Additional Parts or heavily damaged

Neck Cork Dent work

By estimate only

