


1

↓ DJI Fly App




<https://m.dji.net/djifly>





2




3



4





5



6

Power on/off: Press, then press and hold.

开机 / 关机: 短按一次, 再长按 2 秒。



CHT 開機 / 關機: 短按一次, 再長按 2 秒以上。

ID Menghidupkan/mematikan: tekan, lalu tekan dan tahan.

JP 電源をオン/オフ: 1回押し、長押し。

KR 전원 켜기 / 끄기: 한번 누르고 다시 길게 누르기

MS Hidupkan/matikan kuasa: tekan, kemudian tekan dan tahan.

TH បញ្ជាក់/បិទ/បើក: ចុចដាច់ដំបូង រួចចុចរួចចាប់ផ្តើមរយៈពេល

BG Включване/Изключване: натиснете, след това натиснете и задръжте.

CS Zapnutí/vypnutí: stiskněte a poté stiskněte a podržte.

DA Tænd/sluk: Tryk, og tryk derefter igen og hold nede.

DE Ein-/ausschalten: Kurz drücken, dann nochmals drücken und gedrückt halten.

ES Encender/apagar: pulse, vuelva a pulsar y mantenga pulsado.

EL Ενεργοποίηση/απενεργοποίηση: πατήστε και έπειτα πατήστε παρατεταμένα.

FI Virta päälle / pois päältä: paina, ja paina sitten pitkään.

FR Allumer/Éteindre : appuyez une fois, puis appuyez et maintenez le bouton enfoncé pour allumer/éteindre.

HR Uključivanje/isključivanje: pritisnite, a zatim pritisnite i držite.

HU Be- és kikapcsolás: nyomja meg, majd nyomja meg és tartsa lenyomva.

IT Accensione/Spengimento: premere una volta, quindi premere nuovamente e tenere premuto.

NL Aan- en uitzetten: Indrukken, vervolgens indrukken en vasthouden.

NO Slå på/av: trykk, deretter trykk og hold.

PL Włączenie/wyłączenie zasilania: naciśnij, a następnie naciśnij i przytrzymaj.

PT Ligar/desligar: prima, e em seguida prima de forma continua.

PT-BR Ligar/desligar: pressione uma vez, então pressione novamente e segure.

RO Pentru a porni/opri: apăsați lung.

RU Включение/выключение: нажмите, затем нажмите еще раз и удерживайте кнопку.

SK Zapnutie/vypnutie: Stlačte a potom stlačte a podržte.

SV Slå på/av: tryck och håll intryckt.


TR Açma/kapama: Açma kapama tuşuna basin ve basılı tutun.

AR للتشغيل/إيقاف التشغيل: اضغط، ثم اضغط مرة أخرى مع الاستمرار.




DJI AIR 3S

Quick Start Guide 快速入门指南

v1.0



7



<https://s.dji.com/guide86>



Contact
DJI SUPPORT



微信扫一扫
获取技术支持

SUBSCRIBE FOR MORE INFO
关注 DJI 大疆创新及时获取最新资讯



DJI is a trademark of DJI.
Copyright © 2024 DJI All Rights Reserved.



YCBZ5S00286903