



## **YOUR VEHICLE HAS BEEN CERAMIC COATED!**

### **Caring for Your Ceramic Coating:**

Congratulations on your newly applied Duraslic brand ceramic coating! Proper care and maintenance will help you maximize the benefits of your coating and ensure its longevity. Here are some essential instructions on how to care for your ceramic coating:

#### **1. Avoid Washing Your Vehicle for the First 7 Days:**

- To allow the ceramic coating to cure properly, refrain from washing your vehicle for at least seven (7) days after application. This ensures that the coating bonds effectively to your car's surface.

#### **2. Regularly Perform Maintenance Washes:**

- As per the warranty agreement, return to ETX Limited every six (6) months for a maintenance wash. These maintenance washes are provided free of charge. Maintaining a clean and well-maintained surface is crucial for the coating's performance. At which time products designed to restore the coating to the degree possible will be applied.

#### **3. Hand Wash or Use a Touchless Car Wash:**

- When washing your vehicle between maintenance visits, it is highly recommended to hand wash it using a pH-neutral car wash soap and a soft microfiber wash mitt. Alternatively, you can use a touchless car wash that doesn't involve brushes that could potentially damage the coating.

#### **4. Avoid Harsh Chemicals and Abrasives:**

- Do not use harsh chemicals or abrasive cleaning agents on your coated vehicle, as they can compromise the coating's integrity. Stick to mild, pH-neutral car wash soaps and avoid products with high acid content.

**5. Rinse Thoroughly:**

- When washing your vehicle, make sure to rinse it thoroughly to remove all soap residue. Leftover soap can affect the coating's appearance and performance.

**6. Use a Quality Microfiber Towel:**

- For drying your vehicle, use a clean, soft microfiber towel. Avoid using old, abrasive towels that might scratch the surface.

**7. Be Mindful of Environmental Factors:**

- Try to park your vehicle in the shade or in a covered area whenever possible to reduce exposure to harsh sunlight, bird droppings, tree sap, and other environmental contaminants.

**8. Spot Cleaning:**

- If you notice any bird droppings, tree sap, or other contaminants on your vehicle, it's best to remove them promptly. Use a damp microfiber cloth and gently wipe away the spot without applying excessive pressure.

**9. Regular Inspection:**

- Periodically inspect your vehicle's coating for any signs of damage or deterioration. If you notice any issues, contact ETX Limited for evaluation and potential correction, as per your warranty agreement.

**10. Product Usage:**

- Only use PH Neutral products on your vehicle's exterior.
- Use of products not recognized, or authorized by ETX Limited can damage your coating, and void your warranty.

Remember, these instructions are meant to help you maintain your ceramic coating between maintenance visits to ETX Limited. If you have any concerns or questions about your coating's care, feel free to reach out to ETX Limited for guidance. Enjoy the long-lasting protection and enhanced appearance that your Duraslic ceramic coating provides!