

Popcorn Machine Operating Instructions

Popping

1. Turn on two switches, LIGHT (inside cabinet, top left) and KETTLE/MOTOR (next to light switch)
2. Allow kettle to warm for approximately 5 minutes

If using your own mix:

3. Place one measure of oil in kettle (1/4 cup). Immediately add one measure of raw popcorn (6 oz.) plus seasoning salt. Pull lid closed to prevent stray kernels (lid is held in place by magnet directly above the kettle)

*****If using pre-mixed from OBPR: follow directions on package*****

4. While corn is popping, keep front operator doors slightly ajar to prevent fogging
5. Allow corn to pop until popping ceases, usually when 3-4 seconds lapse between pops. Then pour remaining popped corn from kettle by rotating handle clockwise 1/3 turn and pulling downward
6. Turn Kettle switch to OFF position when finished preparing popcorn; LIGHT switch may remain ON to display and heat popcorn

Cleaning

1. Remove all excess popcorn and kernels from the compartment
2. Using a clean cloth wipe down the interior surfaces of popcorn machine

CAUTION: KETTLE WILL BE HOT! Please be sure to avoid direct contact with the kettle during the popping process!

Any problems or issues should be reported to Out Back Party Rentals immediately at either 830-798-2000 or 830-613-9761.

