

KUKJE BL90 Branson Loader

Parts Catalogue



BRANSON TRACTOR

CONTENTS

[illegible]

FIG A001A-1 BL90	BUCKET	Year/Month
		2020/02


FIG 001 BL90	BUCKET	P1	Year / Month	
			2017 / 05	
				


FIG A001A-2

BUCKET(2019~)

Year/Month

BL90

2020/02



TX19-K-001

FIG A003-1 BL90	MOUNTING FRAME ASSEMBLY	Year/Month 2020/02
-------------------------------	--------------------------------	----------------------------------


FIG 002 BL90	MOUNTING FRAME ASS'Y	P1	Year / Month 2017 / 05	
				

FIG A003-2

BL90

MOUNTING FRAME ASS'Y(2019~)

Year/Month

2020/02




FIG A004-1

BL90

BOOM ASSEMBLY

Year/Month

2020/02

FIG 003
BL90

BOOM ASSEMBLY

P1

Year / Month

2017 / 05





FIG A004-3

BOOM ASS'Y(2019~)

Year/Month

BL90

2020/02



[illegible]

FIG A004-4 BL90	BOOM ASS'Y(2019.05~)	Year/Month 2020/02
-------------------------------	-----------------------------	----------------------------------

FIG 004 BL90(S)	BOOM ASSEMBLY	P1	Year / Month 2019 / 05	
-------------------------------	----------------------	-----------	--------------------------------------	---




FIG A005-1 BL90	POST ASSEMBLY	Year/Month 2020/02
-------------------------------	----------------------	----------------------------------




FIG A005-2

BL90

POST ASSEMBLY(2019~)

Year/Month

2020/02




FIG A005-3 BL90	POST ASSEMBLY(2019.05~)	Year/Month 2020/02
-------------------------------	--------------------------------	----------------------------------




FIG A006-1

BL90

STAND

Year/Month

2020/02

FIG 005
BL90

STAND

P1

Year / Month
2017 / 05




FIG A006-2

BL90

STAND(2019~)

Year/Month

2020/02




FIG A007-1 BL90	LOADER VALVE	Year/Month
		2020/02


FIG 006 BL90	LOADER VALVE	P1	Year / Month 2017 / 05	
				

FIG A007-2

BL90

LOADER VALVE

Year/Month


2020/02

FIG 007
BL90S

LOADER VALVE

P1

Year / Month
2018 / 06



[illegible]


FIG A007-3

BL90

LOADER VALVE(2019~)


Year/Month

2020/02



Y319-A-000

FIG A008-1 BL90	HYDRAULIC PIPING ASSEMBLY	Year/Month 2020/02
-------------------------------	----------------------------------	----------------------------------



[illegible]


FIG A008-2

BL90

HYDRAULIC PIPING ASSEMBLY(2019~)

Year/Month

2020/02



[illegible]

FIG A009-1 BL90	BUCKET CYLINDER	Year/Month 2020/02
-------------------------------	------------------------	----------------------------------




FIG A009-2

BL90

BUCKET CYLINDER(2019~)

Year/Month

2020/02




FIG A010-1 BL90	BOOM CYLINDER	Year/Month
		2020/02

FIG 009 BL90	BOOM CYLINDER	P1	Year / Month	
			2017 / 05	




FIG A010-2

BL90

BOOM CYLINDER(2019~)

Year/Month

2020/02




FIG A011A-1 BL90	DECAL-BL90	Year/Month 2020/02
--------------------------------	-------------------	----------------------------------


FIG 010 BL90	DECAL	P1	Year / Month 2017 / 05	
				

FIG A011A-2 BL90	DECAL-BL90(2019~)	Year/Month 2020/02
--------------------------------	--------------------------	----------------------------------


FIG 011 BL90(S)	DECAL	P1	Year / Month 2019 / 05	
				

FIG A012


BL90

JOYSTICK VALVE ASSY

Year/Month

2020/02

8, 9, 10, 11, 16, 18, 19, 21 REPAIR KIT



[illegible]