

KUKJE 8050 Branson Tractor

Parts Catalogue

CONTENTS

GROUP NO	GROUP NAME	PAGE
001D	CYLINDER BLOCK	6
002D.V	V-PULLY_CRANK SHAFT	8
003D	AIR HEATER	10
004D	APPROVAL, AGENCY	12
005D	CRANK SHAFT	14
006D	BREATHER, CRANKCASE	16
007D	CAMSHAFT	18
008D	FRONT GEAR ACCESSORY DRIVE	20
009D	IDLE GEAR	22
010D	ALTERNATOR	24
011D	BALANCE ASS'Y (Page 1)	26
011D-2	BALANCE ASS'Y (Page 2)	28
012D	FAN DRIVE	30
013D	DRIVE PULLY	32
014D	FUEL FILTER	34
015D	FLYWHEEL HOUSING	36
016D	FUEL INJECTION (Page 1)	38
016D-2	FUEL INJECTION (Page 2)	40
017D	PLUMBING, FUEL	42
018D	FLYWHEEL	44
019D-1	COVER, FRONT GEAR	46
020D	HEAD, CYLINDER	48
021D	CONNECTION, AIR INTAKE	50
022D	MANIFOLD, INTAKE	52
023D	INJECTOR	54
024D	ARRANGEMENT, LIFTING	56
025D	COOLER, ENGINE OIL	58
026D	FILTER, LUBRICATING OIL	60
027D	GAUGE, OIL LEVEL	62
028	PTO & MAIN DAMPER	64
028D	PUMP, LUBRICATING OIL	66
029	MAIN PUMP	68
029D	NOZZLE, PISTON COOLING	70
030	STEERING HYDRUALIC LINE	72
030D	ARRANGEMENT, OIL FILL	74

GROUP NO	GROUP NAME	PAGE
031	OIL COOLER	76
031D	OIL PAN	78
032	PTO LUB	80
032D	PISTION	82
033	HYDRAULIC FILTER	84
033D	LEVER, LOCKER	86
034	SELECTING CONTROL V/V ASSY	88
034D	MOTOR, STARTING	90
035	LINE FILTER ASSY	92
035D	PLUMBING, TURBO CHARGER	94
036	DIVIDER VALVE	96
036D	TURBO CHARGER	98
037	BRAKE HYDRAULIC LINES	100
037D	COVER, VALVE	102
038	BRAKE VALVE	104
038D	PUMP, WATER	106
039	BRAKE PEDAL	108
039D	MANIFOLD, EXHAUST	110
040	RADIATOR ASSY	112
040D	SILENCER	114
041	TANK	116
042	FRONT AXLE BRACKET	118
043	FRONT AXLE SUPPORTER	120
044	PROPELLER SHAFT	122
045	AIR CLEANER	124
046	BATTERY	126
047	AIR CONDITIONER SYSTEM	128
048	TENSION PULLY	130
049	FUEL TANK BRACKET	132
050-1	FUEL TANK	134
050-2	FUEL TANK	136
051	MUFFLER	138
052	EXHAUST PIPE	140
053	SUB STEP	142
054	CABIN MOUNTING ASSY	144

GROUP NO	GROUP NAME	PAGE
055	BONNET BRACKET ASSY	146
056	BONNET ASSY	148
056-2	BONNET ASSY	150
057	ACCELERATION SYSTEM	152
058	HORN	154
059	STEERING COLUMN	156
060	COLUMN STAY & CLUTCH PEDAL	159
061	DRAFT LINK	161
062	CENTER LINK ASSY	163
063	LIFT LINK ASSY	165
064	HITCH SENSOR ASSY	167
065	DRAWBAR HITCH	169
066	PTO COVER ASSY	171
067	SHIFT LEVER ASSY	173
068	DIFF-LOCK PEDAL ASSY	175
069	COVER ASSY	177
070	PARKING BRAKE LEVER	179
071	REAR SCV LEVER ASSY	181
072	PTO SHIFT	183
073	T/M OIL IN-LET ASSY	185
074	DRIVER'S SEAT ASSY	187
075	ROPS FRAME ASSY	189
076	DASH BOARD ASSY	191
077	LEFT FENDER COVER	193
078	RIGHT FENDER COVER	195
079	FENDER ASSY	197
080	MID-SCV JOY-STICK	199
081	PILLAR COVER ASSY	201
082	WASHER LIQUID TANK	203
083	SUN-ROOF ASSY	205
084	SIDE-VIEW MIRROR ASSY	207
085	RADIO ASSY	209
086	DOOR ASSY	211
087	REAR SIDE WINDOWS	213
088	WINDSHIELD ASSY	215

GROUP NO	GROUP NAME	PAGE
089	REAR WINDOWS ASSY	217
090	WORK LIGHT ASSY	219
091	A/C CONTROLLER ASSY	221
092	A/C DUCT ASSY	223
093	ROOF OUTER ASSY	225
094	ROOF ASSY	227
095	CONTROLLER ASSY	229
096	A/C ASSY	231
097	BLOCK PLATE ASSY	233
098-1	LABEL (Page 1)	235
098-2	LABEL (Page 2)	237
099	FUSE BOX ASSY	239
100-1	HARNESS ASSY (Page 1)	241
100-2	HARNESS ASSY (Page 2)	243
101	SPARE TOOLS	245
S001	OSCILLATION CASE	247
S002	DIFFERENTIAL	249
S003	FRONT 1ST SHAFT	251
S004	F/A REDUCTION	253
S005	STEERING	255
T005	FBR VALVE	257
T006	MAIN SHAFT	260
T007	TM PUMP KIT	262
T008	FBR CLUTCH	264
T009	DRIVE SHAFT	266
T010	SYNCHRO	268
T011	SUB DRIVE	270
T012	COUNTER SHAFT	272
T013	DIFFERENTIAL	274
T014	RING GEAR&DIFF.GEAR ASS'Y	276
T015	STRAINER	278
T016	PTO CLUTCH SHAFT	280
T017	PTO SHAFT	282
T018	PTO COVER	284
T019	PARKING BRAKE	286

[illegible]

FIG 001D

8050

CYLINDER BLOCK

Year/Month

2020/01




FIG 002D.V

8050

V-PULLY_CRANK SHAFT

Year/Month

2020/01





FIG 003D

8050

AIR HEATER

Year/Month

2020/01



[illegible]

FIG 004D

8050

APPROVAL, AGENCY

Year/Month

2020/01




FIG 005D

8050

CRANK SHAFT

Year/Month

2020/01




FIG 006D

8050

BREATHER, CRANKCASE

Year/Month

2020/01




FIG 007D

8050

CAMSHAFT

Year/Month

2020/01




FIG 008D

8050

FRONT GEAR ACCESSORY DRIVE

Year/Month

2020/01




FIG 009D

8050

IDLE GEAR

Year/Month

2020/01




FIG 010D

8050

ALTERNATOR

Year/Month

2020/01




FIG 011D

8050

BALANCE ASS'Y (Page 1)

Year/Month

2020/01




FIG 011D-2

8050

BALANCE ASS'Y (Page 2)

Year/Month

2020/01





FIG 012D

8050

FAN DRIVE

Year/Month

2020/01



[illegible]


FIG 013D

8050

DRIVE PULLEY

Year/Month

2020/01



[illegible]

FIG 014D

8050

FUEL FILTER

Year/Month

2020/01




FIG 015D

8050

FLYWHEEL HOUSING

Year/Month

2020/01





FIG 016D

8050

FUEL INJECTION (Page 1)

Year/Month

2020/01



[illegible]

FIG 016D-2

8050

FUEL INJECTION (Page 2)

Year/Month

2020/01




FIG 017D

8050

PLUMBING, FUEL

Year/Month

2020/01




FIG 018D

8050

FLYWHEEL

Year/Month

2020/01




FIG 019D-1

8050

COVER, FRONT GEAR

Year/Month

2020/01




FIG 020D

8050

HEAD, CYLINDER

Year/Month

2020/01




FIG 021D

8050

CONNECTION, AIR INTAKE

Year/Month

2020/01




FIG 022D

8050

MANIFOLD, INTAKE

Year/Month

2020/01




FIG 023D

8050

INJECTOR

Year/Month

2020/01




FIG 024D

8050

ARRANGEMENT, LIFTING

Year/Month

2020/01




FIG 025D

8050

COOLER, ENGINE OIL

Year/Month

2020/01




FIG 026D

8050

FILTER, LUBRICATING OIL

Year/Month

2020/01





FIG 027D

GAUGE, OIL LEVEL

Year/Month

8050

2020/01



[illegible]

FIG 028

8050

PTO & MAIN DAMPER

Year/Month

2020/01




FIG 028D

8050

PUMP, LUBRICATING OIL

Year/Month

2020/01




FIG 029

8050

MAIN PUMP

Year/Month

2020/01




FIG 029D

8050

NOZZLE, PISTON COOLING

Year/Month

2020/01





FIG 030 8050	STEERING HYDRUALIC LINE	Year/Month 2020/01
----------------------------	--------------------------------	----------------------------------



[illegible]

FIG 030D

8050

ARRANGEMENT, OIL FILL

Year/Month

2020/01




FIG 031

8050

OIL COOLER

Year/Month

2020/01




FIG 031D

8050

OIL PAN

Year/Month

2020/01




FIG 032

PTO LUB

Year/Month

8050

2020/01




FIG 032D

8050

PISTON

Year/Month

2020/01




FIG 033

8050

HYDRAULIC FILTER

Year/Month

2020/01




FIG 033D

8050

LEVER, LOCKER

Year/Month

2020/01




FIG 034

8050

SELECTING CONTROL V/V ASSY

Year/Month

2020/01




FIG 034D

8050

MOTOR, STARTING

Year/Month

2020/01





FIG 035

8050

LINE FILTER ASSY

Year/Month

2020/01



[illegible]


FIG 035D

8050

PLUMBING, TURBO CHARGER

Year/Month

2020/01



[illegible]

FIG 036

8050

DIVIDER VALVE

Year/Month

2020/01




FIG 036D

8050

TURBO CHARGER

Year/Month

2020/01




FIG 037

8050

BRAKE HYDRAULIC LINES

Year/Month

2020/01




FIG 037D

8050

COVER, VALVE

Year/Month

2020/01





FIG 038

8050

BRAKE VALVE

Year/Month

2020/01



[illegible]

FIG 038D

8050

PUMP, WATER

Year/Month

2020/01




FIG 039

8050

BRAKE PEDAL

Year/Month

2020/01




FIG 039D

8050

MANIFOLD, EXHAUST

Year/Month

2020/01





FIG 040

8050

RADIATOR ASSY

Year/Month

2020/01



[illegible]

FIG 040D

8050

SILENCER

Year/Month

2020/01




FIG 041

8050

TANK

Year/Month

2020/01





FIG 042

8050

FRONT AXLE BRACKET

Year/Month

2020/01



[illegible]

FIG 043

8050

FRONT AXLE SUPPORTER

Year/Month

2020/01




FIG 044

8050

PROPELLER SHAFT

Year/Month

2020/01




FIG 045

8050

AIR CLEANER

Year/Month

2020/01




FIG 046

8050

BATTERY

Year/Month

2020/01





FIG 047

8050

AIR CONDITIONER SYSTEM

Year/Month

2020/01



[illegible]


FIG 048

8050

TENSION PULLEY

Year/Month

2020/01



[illegible]

FIG 049

8050

FUEL TANK BRACKET

Year/Month

2020/01





FIG 050-1

8050

FUEL TANK

Year/Month

2020/01



[illegible]

FIG 050-2

8050

FUEL TANK

Year/Month

2020/01




FIG 051

8050

MUFFLER

Year/Month

2020/01




FIG 052

8050

EXHAUST PIPE

Year/Month

2020/01




FIG 053

8050

SUB STEP

Year/Month

2020/01




FIG 054

8050

CABIN MOUNTING ASSY

Year/Month

2020/01




FIG 055

8050

BONNET BRACKET ASSY

Year/Month

2020/01




FIG 056

BONNET ASSY

Year/Month

8050

2020/01





FIG 056-2

8050

BONNET ASSY

Year/Month

2020/01



[illegible]


FIG 057

8050

ACCELERATION SYSTEM

Year/Month

2020/01



[illegible]

FIG 058

8050

HORN

Year/Month

2020/01




FIG 059

8050

STEERING COLUMN

Year/Month

2020/01




FIG 059		STEERING COLUMN			Year/Month
8050					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	TA00016894A	CAP	1		
2	26347-080002	Unut	1		
3	FB29170000A4	Reinforcement Washer	2		
4	FB29180000A3	Adjustment lever	1		
5	TZ29030000A1	STEERING WHEEL	1		
6	26357-160002	NUT	1		
7	22137-160000	WASHER, PLAIN (Φ 16)	1		
8	TA00016273C	COLUMN SWITHC ASSY	1		
9	TA00016445A	BOOTS	1		
10	22242-000200	SNAP RING, SHAFT (Φ 20)	1		
11	22252-000420	RING, CIRCLIP (Φ 42)	1		
12	22242-000250	SNAP RING, SHAFT (Φ 25)	1		
13	24104-069054	BALL BEARING	1		
14	TA00000561A	COLUM PIPE ASSY	1		
15	TA00016271A	GUIDE	1		
16	26577-050162		3		
17	24107-069064	DEEP GROOVE BALL BEARING	1		
18	22242-000301	SNAP RING, SHAFT (Φ 30)	1		
19	22262-000470	RING, CIRCLIP (Φ 47)	1		
20	TA00000565B	STEERING COLUM ASSY	1		
21	26106-120252	HEX FLANGE BOLT	4		
22	TA00000571A	BOLT	2		
23	26367-050002	HEX FLANGE NUT Φ5)	2		
24	TA00000546A	HINGE BRACKET	2		
25	TA00000538A	TILT STOPER RH	1		
26	26553-050102		4		
27	TA00000537A	TILT STOPER LH	1		
28	TA00000544B	STEERING COLUM ASSY	1		
29	TA00000555A	BRACKET	1		
30	26106-050142	HEX FLANGE BOLT (5-14)	2		
31	26716-100002	Nut, Hexa (Φ10)	1		
32	TA00000576A	GAS SPRING	1		
33	22312-100500	PARRELL PIN	1		
34	26106-100162	SCREW,HEXFLANGEHEADCAP	4		
35	TA00000577A	BRACKET	1		
36	TA00016409A	BOLT	2		
37	22351-030025	PIN, SPRING (3-02)	1		
38	22351-050045	PIN	1		
39	TA00016447B	TILTING LEVER	1		
40	TA00016480A	TILING KNOB	1		
41	22587-480206	TAPPING SCREW	8		
42	26023-040102	SCREW W/WASHER	2		
43	TA00016259A	COVER	1		
44	HA00000084A	REVERSER LEVER	1		
45	TA00016258A	STEERING COLUMN SWITCH UP	1		


FIG 060

8050

COLUMN STAY & CLUTCH PEDAL

Year/Month

2020/01



[illegible]

FIG 061

8050

DRAFT LINK

Year/Month

2020/01





FIG 062

8050

CENTER LINK ASSY

Year/Month

2020/01



[illegible]

FIG 063

8050

LIFT LINK ASSY

Year/Month

2020/01




FIG 064

8050

HITCH SENSOR ASSY

Year/Month

2020/01





FIG 065

8050

DRAWBAR HITCH

Year/Month

2020/01



[illegible]

FIG 066

8050

PTO COVER ASSY

Year/Month

2020/01





FIG 067

8050

SHIFT LEVER ASSY

Year/Month

2020/01



[illegible]

FIG 068

8050

DIFF-LOCK PEDAL ASSY

Year/Month

2020/01




FIG 069

8050

COVER ASSY

Year/Month

2020/01




FIG 070

8050

PARKING BRAKE LEVER

Year/Month

2020/01





FIG 071

8050

REAR SCV LEVER ASSY

Year/Month

2020/01



[illegible]

FIG 072

8050

PTO SHIFT

Year/Month

2020/01




FIG 073

8050

T/M OIL IN-LET ASSY

Year/Month

2020/01




FIG 074

DRIVER'S SEAT ASSY

Year/Month

8050

2020/01





FIG 075

8050

ROPS FRAME ASSY

Year/Month

2020/01



[illegible]

FIG 076

8050

DASH BOARD ASSY

Year/Month

2020/01





FIG 077

8050

LEFT FENDER COVER

Year/Month

2020/01



[illegible]

FIG 078

8050

RIGHT FENDER COVER

Year/Month

2020/01




FIG 079

8050

FENDER ASSY

Year/Month

2020/01





FIG 080

8050

MID-SCV JOY-STICK

Year/Month

2020/01



[illegible]

FIG 081

8050

PILLAR COVER ASSY

Year/Month

2020/01





FIG 082

8050

WASHER LIQUID TANK

Year/Month

2020/01



[illegible]


FIG 083

8050

SUN-ROOF ASSY

Year/Month

2020/01



[illegible]

FIG 084

8050

SIDE-VIEW MIRROR ASSY

Year/Month

2020/01




FIG 085

8050

RADIO ASSY

Year/Month

2020/01





FIG 086

8050

DOOR ASSY

Year/Month

2020/01



[illegible]

FIG 087

8050

REAR SIDE WINDOWS

Year/Month

2020/01




FIG 088

8050

WINDSHIELD ASSY

Year/Month

2020/01





FIG 089

8050

REAR WINDOWS ASSY

Year/Month

2020/01



[illegible]

FIG 090

8050

WORK LIGHT ASSY

Year/Month

2020/01




FIG 091

8050

A/C CONTROLLER ASSY

Year/Month

2020/01





FIG 092

8050

A/C DUCT ASSY

Year/Month

2020/01



[illegible]


FIG 093

8050

ROOF OUTER ASSY

Year/Month

2020/01



[illegible]

FIG 094

8050

ROOF ASSY

Year/Month

2020/01




FIG 095

8050

CONTROLLER ASSY

Year/Month

2020/01





FIG 096

8050

A/C ASSY

Year/Month

2020/01



[illegible]


FIG 097

8050

BLOCK PLATE ASSY

Year/Month

2020/01



[illegible]

FIG 098-1

8050

LABEL (Page 1)

Year/Month

2020/01





FIG 098-2 8050	LABEL (Page 2)	Year/Month 2020/01
 8 Branson 8050 Tractor 8050 4 8050 Branson 3 7 CAUTION Do not touch the muffler it can cause a burn. FIG 07000004  Branson 8050 2 9 WARNING  10 WARNING 		


FIG 099

8050

FUSE BOX ASSY

Year/Month

2020/01



[illegible]

FIG 100-1

8050

HARNESS ASSY (Page 1)

Year/Month

2020/01





FIG 100-2

8050

HARNESS ASSY (Page 2)

Year/Month

2020/01



[illegible]

FIG 101 8050	SPARE TOOLS	Year/Month 2020/01
1  2 		

FIG S001

8050

OSCILLATION CASE

Year/Month

2020/01




FIG S002

8050

DIFFERENTIAL

Year/Month

2020/01





FIG S003

8050

FRONT 1ST SHAFT

Year/Month

2020/01



[illegible]


FIG S004

8050

F/A REDUCTION

Year/Month

2020/01



[illegible]

FIG S005

8050

STEERING

Year/Month

2020/01




FIG T005

8050

FBR VALVE

Year/Month

2020/01




FIG T005		FBR VALVE			Year/Month
8050					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	TA00018754C	FR VALVE ASSY	1		
2	TA00018640C	F/R VALVE BODY	1		
3	TA00018600A	PROPORTIONAL VALVE	1		
4	TA00018641B	RETENTION BRACKET	1		
5	26106-100202	HEX BOLT, (10-20)	1		
6	TA00018663A	O-RING	1		
7	TA00018601A	ON/OFF VALVE	2		
8	TA00018610A	ON,OFF SPOOL	2		
9	TA00018606A	SPRING	2		
10	TA00019864A	PRESSURE SENSOR, POWRREVERSE	1		
11	TA00018637A	WASHER	1		
12	TA00018468A	MAIN RELIEF VALVE	1		
13	TA00018609A	MAIN RELIEF V/V SLEEVE	1		
14	TA00018605A	MAIN SPRING OUT	1		
15	TA00018604A	MAIN SPRING IN	1		
16(0.3T)	TA00018643A	SEAM 0.3	1		
16(0.2T)	TA00018644A	SEAM0.2	1		
16(0.5T)	TA00019935A	SEAM (0.5T)	1		
17	24311-000290	O-RING, DYNAMIC (Φ29)	1		
18	TA00018492A	PLUG PF1	1		
19	TA00018491A	PLUG PF1 ASS'Y	1		
20	TA00018638A	LUB.SPOOL	1		
21	TA00018608A	SPRING	1		
22	24311-000180	O-RING, DYNAMIC (Φ18)	3		
23	TA00018642A	PLUG PF1/2	1		
24	TA00018650A	PLUG	1		
25	TA00018501A	STRAINER	1		
26	TA00018672A	SPRING	1		
27	TA00018496A	PLUG M20*P1.5	1		
28	TA00018495A	PLUG M20*P1.5 ASS'Y	1		
29	TA00018651A	PLUG	1		
30	TA00018652A	PLUG ASSY(PF1/2)	1		
31	TA00018607A	SPRING	2		
32	TA00018639B	SHUTTLE SPOOL	1		
33	23871-010000	PLUG	10		
34	23871-020000	Plug, Pipe	2		
35	TA00017592A	GASKET	2		
36	TA00017591A	GASKET PLATE	1		
37	TA00018673A	SUB PLATE	1		
38	FGF5200000A3	PACKING	1		
39	TA00018654A	PACKING	1		
40	TA00018653A	PLATE	1		
41	26013-080162	Bolt, Hexa (8-16)	2		
42	26216-080652	BOLT	2		
43	26716-080002	NUT,HEX (D8)	2		

FIG T006

8050

MAIN SHAFT

Year/Month

2020/01





FIG T007

8050

TM PUMP KIT

Year/Month

2020/01



[illegible]


FIG T008

8050

FBR CLUTCH

Year/Month

2020/01



[illegible]

FIG T009

8050

DRIVE SHAFT

Year/Month

2020/01





FIG T010

8050

SYNCHRO

Year/Month

2020/01



[illegible]

FIG T011

8050

SUB DRIVE

Year/Month

2020/01




FIG T012

8050

COUNTER SHAFT

Year/Month

2020/01




FIG T013

8050

DIFFERENTIAL

Year/Month

2020/01




FIG T014

8050

RING GEAR&DIFF.GEAR ASS'Y

Year/Month

2020/01




FIG T015

8050

STRAINER

Year/Month

2020/01





FIG T016

8050

PTO CLUTCH SHAFT

Year/Month

2020/01



[illegible]

FIG T017

8050

PTO SHAFT

Year/Month

2020/01





FIG T018

8050

PTO COVER

Year/Month

2020/01



[illegible]


FIG T019

8050

PARKING BRAKE

Year/Month

2020/01



[illegible]

FIG T020

8050

MAIN,SUB SHIFT

Year/Month

2020/01




FIG T021

8050

SHIFT CASE

Year/Month

2020/01




FIG T022

8050

4WD ASSY

Year/Month

2020/01




FIG T022		4WD ASSY			Year/Month
8050					2020/01
KeyNo.	Part Number	Part Name	Quantity	Other	
1	TT64070000A4	SEAL RING	1		
2	TT61070000B	SPACER	2		
3	TT52150000A9		1		
4	TB28120000C	PLUG	1		
5	TA00018910A	OIL SEAL	1		
6	TA00016392A	WASHER(4WD)	1		
7	TA00016377B	4WD CLUTCH PACK ASSY	1		
8	TA00016378A	PLATE	1		
9	TA00016376A	STEEL PLATE(4WD)	6		
10	TA00016375B	FRICTION PLATE(4WD)	6		
11	TA00016374A	SPRING(4WD)	1		
12	TA00016373A	SNAP RING(4WD)	1		
13	TA00016372A	4WD D-RING	1		
14	TA00016371A	4WD PISTON	1		
15	TA00016370A	4WD CYLINDER	1		
16	TA00016369A	4WD 피동기어	1		
17	TA00016368B	4WD GEAR	1		
18	TA00016367C	4WD COVER	1		
19	TA00016366A	4WD CLUTCH GEAR	1		
20	TA00016364A	4WD SHAFT ASSY	1		
21	FGH9330000A4	WASHER(15X34X4.5)	1		
22	FGH9280011A	COLLAR(FWD)	1		
23	FGH9280000A4	BEARING(4T30305)	2		
24	FGH9270000B	SHAFT, 4WD DRIVEN	1		
25	FGH9110000A3	KEY(7X5X50)	1		
26	FGG8260000A3	SOLENOID VALVE	1		
27	26877-140002		1		
28	26106-080302	HEX BOLT, FLANGE	4		
29	24321-001450	O RING	1		
30	24311-001250	O-ring	1		
31	24311-000380	O-RING, DYNAMIC (Φ38)	1		
32	24311-000160	O-RING, DYNAMIC (Φ16)	1		
33	24101-063094	BALL BEARING #6309	1		
34	24101-062064	BALL BEARING (#6206)	2		
35	23871-010000	PLUG	3		
36	22414-320250		1		
37	22351-060050	PIN, SPRING (6-50)	1		
38	22351-035032	PIN, SPRING (3.5-32)	1		
39	22312-100160		2		
40	22252-000620	RING, CIRCLIP (Φ 62)	1		
41	22242-000400	SNAP RING, SHAFT (Φ 40)	1		
42	22242-000300	SNAP RING, SHAFT (Φ 30)	2		
43	TA00016363D	4WD ASSY	1		

FIG T023	HYDRAULIC CYLINDER ASSY	Year/Month
8050		2020/01





FIG T024

8050

CASE ASSY

Year/Month

2020/01



[illegible]

FIG T025

8050

PIPE ASSY

Year/Month

2020/01




FIG T026

8050

REAR AXLE ASSY

Year/Month

2020/01




FIG T027

8050

BRAKE

Year/Month

2020/01

