

# **EZFill Quick Start Guide**

## **Step-by-Step Cylinder Refill after the Initial Compressor Set-up**

- 1) Fill your EZEssentials bucket with cold water, just above the EZAir Systems logo. Place ice packs in the water.**
- 2) Loosen Valve Knobs labeled 1 & 2.**
- 3) Place the pump into the bucket of water.**
- 4) Plug the pump and compressor into the provided 3-way plug & plug into your outlet. Check that water is circulating.**
- 5) Turn on your EZFill Compressor & allow the temp to reach 30C.**
- 6) Attach the large oil/water separator to the system.**
- 7) Tighten Valve Knobs, 1 then 2.**
- 8) Connect the cylinder to be filled to the preset PSI, keeping the cylinder upright.**
- 9) When the cylinder is full, an alarm will sound & the compressor will shut down automatically.**
- 10) Switch the Compressor to 'OFF'. Then loosen Valve Knobs 1, then 2.**
- 11) Disconnect your filled cylinder from the system.**
- 12) Repeat Steps 4 to 11 as needed. Checking the water temperature periodically.**

**Once all refills are complete, unplug from the wall, discard the water & store as needed.**