

IC-9100

PA-A Unit


(Power Tap – 10v)

RF-B Unit

VHF Tap

UHF Tap

TOP VIEW



PA-B Unit

BOTTOM VIEW

BPF Unit

RF-A Unit

HF Tap (Located above BPF Unit)




UX-9100 MAIN-B Unit (Top)

23cm Tap Point




HF Post RF Amp Tap Point




RF-A Unit (Top)

HF Post RF Amp Tap Point



RF-A Unit (Top)

HF Post RF Amp Tap Point



PA-A Unit

Power Tap – J403 Pin 5 10V

IC-9100_Service_manual.pdf (SECURED) - Adobe Acrobat Reader DC

File Edit View Window Help

Home Tools IC-9100_Service_m... x

David

111 / 163 150%

• PA-A UNIT
(TOP VIEW)

Diagram of the PA-A Unit (Top View) showing various components and connections. A red dot is placed on Pin 5 of J403, which is labeled '10V'. A red arrow points from the text 'Power Tap – J403 Pin 5 10V' to this dot.

16.54 x 11.69 in

Windows Taskbar



10:33 PM 6/4/2018

VHF Post RF Amp Tap

—


 [Sign In](#)

 [Sign In](#)



RF-B Unit


UHF Post RF Amp Tap



RF-B Unit


UHF Tap Point

VHF Tap Point




RF-B Unit (Top)

VHF Post RF Amp Tap Point



RF-B Unit (Top)

UHF Post RF Amp Tap Point



UX-9100 MAIN-B Unit (Top)

23cm Post RF Amp Tap Point

UX-9100_Service_Manual.pdf - Adobe Acrobat Reader DC

File Edit View Window Help

Home Tools UX-9100_Service_... IC-9100 RF & Pow...

David

Save Print Mail Search

26 / 36

45.5%

Hand Mouse

Zoom In Zoom Out

Find

Comment

Tools

SECTION 7 BOARD LAYOUTS

MAIN-B UNIT (TOP VIEW)

7-1

Windows Taskbar

10:26 PM 6/4/2018

UX-9100 MAIN-B Unit (Top)

23cm Tap Point – C288

