

SR Glass Tube Extension

Made for early SR 300, 340, 500, and 700 Roasters. Will not fit SR540 and SR580

Caution: Top Assembly will not be secure with the glass tube extension. Be cautious with using the extension.

Caution: Do not try and move the machine as one unit. Separate the parts when moving the unit.

1. Each tube has 1 flat silicone seal, 1 round seal, and 1 glass extension tube.



2. Slide the round seal about 2 inches from the bottom the the tube.

3. Put the flat seal on the tube so it is flush the the bottom of the roast chamber.

4. Push the extension tube into the existing chamber until it seats itself on the bottom screen.

5. Add your beans and roast as you have in the past.

