


Open Frame Wall Mount Rack



THIS MANUAL APPLIES TO THE FOLLOWING SKUs:

00600318

00600319

Thank you for purchasing the Open Frame Wall Mount Rack from RackPath. Every effort has been made to ensure the accuracy of the information in this product manual.

Important Safety Instructions

Please call or email us if you have any concerns about the installation or use of your product. Please inspect the product for any missing or defective components. Ask RackPath for help if any component is broken or missing. If the product has been affected, do not try to install or use it. To prevent harm during assembly, place the product contents on cardboard or another safe surface. Improper installation or use of this product can result in product damage, other damage to equipment, or personal injury.


It is advised that the installation be performed by a professional installer. RackPath cannot be held liable for equipment damage or physical injuries resulting from inappropriate product usage or installation. Please ensure that the equipment stored/mounted should not exceed the stated weight capacity.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to RackPath. These references are provided for informational purposes only and do not represent an endorsement of a product or service by RackPath, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, RackPath hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related document are the property of their respective holders.


Limitations of Liability: RackPath Network Equipment (Yunnan) Co. Ltd will not be responsible for any injury or damage, whether direct or indirect, special, punitive, incidental, or consequential damages (including, but not limited to, lost profits or revenue, loss of use, lost business opportunities, or loss of goodwill), or the costs of procuring substitute products, arising out of or in connection with the use of the product. In no case can seller's gross accumulated liability, arising from all causes of action and theories of liability, exceed the total sums actually charged by customer to seller under the order giving rise to any liability hereunder.

Rack Configuration & Installation




	Accessories List			
1: Front Frame 2: Side Frames (x2)	A: M6 Installation Screws	6U x8;	9U x8	
	B: M6 Mounting Screws	6U x12;	9U x18	
	M6 Cage Nuts	6U x12;	9U x18	
	M6 Plastic Washers	6U x12;	9U x18	
	C: 12-24 Mounting Screws	6U x12;	9U x18	
	D: M6 Wall Mounting Screws	6U x6;	9U x6	

Installation



Attach Front Frame (#1) to the Side Frames (#2) and secure them with 8 of the M6 Installation Screws (Bag A).



Attach the rack to a wall or other suitable mounting surface using M6 Wall Mounting Screws and M6 Metal Washers (Bag D). Mounting holes are spaced 16" (406.4mm) apart to accommodate standard stud placement as reflected in the diagram.

Warning: Do not attempt to mount to wall when equipment is mounted inside the rack. The rack has a weight capacity of 150 pounds. Make sure the type of wall structure and mounting hardware that you are using will properly support the weight of the rack and equipment.