

Our Erotic™
Journey

Enchantress Palm Massager

Instructions

PLEASE READ CAREFULLY BEFORE USING THE PRODUCT

Fully Charge before use.


Product Specification

Product Name: Enchantress Palm Massager
Waterproof Capability : IPX6 Grade
Material : ABS + Medical Grade Silicone
Secondary charge: 120 minutes
Use time is about 90 minutes
Max Noise : less than 55 db
Power : Rechargeable Battery(USB Cable Included)
Weight:133g

Product Features

1. Fashion and beautiful appearance with mushroom-shaped design, can evenly massage your back, legs, chest, waist and any positions on body, effectively relieve the soreness caused by muscle pain.
2. 10 Multi vibration frequency which can stimulate and massage any parts on body, also be used for fun to stimulate sensitive areas, bring your body and soul pleasure.
3. High-end custom built-in motor, ultra-quiet, more powerful vibration and longer useful life.
4. The charging setting is simple, the indicator light will flash when charging, and the indicator light is always on when it is full.

Product Diagram



Method of Use

- Turn On / Off:** Press and hold the middle button "(" for 3 seconds to turn on, and hold for 3 seconds to turn off.
- Forward gears:** Press the "+" button as the forward gear position, each press will switch one frequency for a total of 10 cycle frequencies.
- Back the tests:** Press the "-" button as the reverse gear, each press will switch one frequency for a total of 10 cycle frequencies.

NOTICE

1. Please charge the product for 35 minutes before using it, Since the product will affect the vibration intensity of the product when the battery is low.
2. Before and after using the product, please clean it with warm water or neutral lotion.
3. The product store in a dry and cool place and avoid sunlight after cleaning.
4. Please do not place the product on over 70 degrees.
5. Please stop using the product immediately when you feeling abnormal.
6. The product can be used with professional lubricants or massage oils.
7. Please stop using product immediately if it is damaged.

Storage:

1. We recommend store vibrator in ventilated place. Avoid direct sun exposure, high temperature and humidity moisture place
2. Keep the surface dry without any water stains and then store it in a storage bag.

Sweet Tips:

1. Vibrator is personal product. Please don't share it with others and avoid caused health issues
2. Please stop use if any discomfort when you using
3. Please don't use it when you are ill or wake for your safety
4. It is designed to help release tight muscles, prevent injury and lead to more effective warm up and recovery.