

Our Erotic Journey<sup>®</sup>

# Remote control anal plug THE MAX

## Instructions

PLEASE READ CAREFULLY BEFORE USING THE PRODUCT

Fully Charge before use.

### Product Specification:

- Remote control (Li-MnO<sub>2</sub> Button Cell Included)
- Material: Medical Grade Silicone
- Waterproof rating: IPX7 (submersible)
- Frequency: 10 Speeds Vibration
- Size: 5.12" x 2.81" x 1.77"

### Product Features:

Expand your pleasure with "THE MAX", this silky smooth silicone plug will vibrate within you for an unbelievable sensation of buzzes.

Treat yourself or your partner with 10 modes of vibration, with easy control from the remote. Ipx7 waterproof for long lasting wet and wild play.

### USE GUIDE:


#### Power button on toy:

Hold down power button to switch On/Off  
When power is on , press power button again to switch mode

#### Buttons on controller:

Press power button to switch mode , long press power button for 3 seconds to turn off the toy

Power/Vibration button



### Charge:

1. The toy can't be running while charging.
2. The indicator light will blink when the charging cable is connected with charging port .
3. The indicator will stop blink and keep lighting when the toy is fully charged.

### Change battery of controller:

Open the back battery compartment ,  
Use a new "CR2032" Lithium battery to replace the old one,make sure negative pole facing inside

### NOTICE:

- 1.Please charge the product for 1 hour before using it, Since the product will affect the vibration intensity of the product when the battery is low.
- 2.Before and after using the product, please clean it with warm water or neutral lotion.
- 3.The product store in a dry and cool place and avoid sunlight after cleaning.
- 4.Please do not place the product on over 70 °F.
5. Please stop using the product immediately when you are feeling abnormal.
- 6.The product can be used with water-based lubricants or massage oils.  
Silicone-based lubricants and massage oils are absolutely prohibited.
- 7.Please stop using product immediately if it is damaged.

### Storage:

- 1.We recommend store vibrator in ventilated place.Avoid direct sun exposure, high temperature and humidity moisture place
- 2.Keep the surface dry without any water stains and then store it in a storage bag.

### Sweet Tips:

- 1 Vibrator is personal product. Please don't share it with others and avoid caused health issues
- 2.Please stop use if any discomfort when you using
- 3.Please don't use it when you are ill or wake for your safety
- 4.It is designed to help release tight muscles,prevent injury and lead to more effective warm up and recovery.