

# Tickled Pink QUICKSTART GUIDE

*Our Erotic<sup>®</sup>  
Journey*

**TURN ME ON**

**1**



**HOLD**  
for 3 SEC

TURN ON/OFF THE DEVICE

**PLAY WITH ME**

**2**



**CLICK**  
to SWITCH

SWITCH BETWEEN 10 MODES

**ENERGIZE ME**

**3**



**USB**

USE THE SUPPLIED  
USB CHARGING CABLE

POWER ADAPTER NOT INCLUDED

**IPX6**  
WATER RESISTANT

**10**  
MODES

**60**  
MINUTE RUNTIME

