

BOSCH 2000 ALARM SYSTEM



Instructions for changing your alarm code.

1. Enter your existing code directly followed by a "1".

(The standard alarm code at handover is 1234, so if this is the first time you are changing your code you will be entering 12341.)

2. Press "AWAY", "1", "AWAY"
3. Enter you new code and press "AWAY".

If you are still having difficulty, feel free to contact us at reception@jbegroup.com.au.