

YOOSURE FLIP

Dual-Height Camping Stool



Two Height
Options




Built-In
Armrest



Light weight
& Portable



Supports up to
250 lbs



13.8" H

LOW MODE



16.5" H

HIGH MODE




Use both hands to bring
Bar A and Bar B together.



Slide Bar C to
the opposite side.


YOOSURE FLIP

— HOW TO USE —



STEP 1

Insert the 4 legs by matching the numbers (1-4) correspondingly.



STEP 2

Choose your preferred height option.



STEP 3

Attach the outer bag to the armrest as a storage pouch.



STEP 4

Fold compactly to stand upright for grab-and-go portability.

SAFETY & CARE

- Use on flat, stable ground.
- Check all legs before sitting.
- Do not exceed rated weight capacity (250 lbs).
- Keep away from sharp objects and open flame.
- Wipe clean and store dry.



— U.S. Patent —