

YOOSURE CAMPING

YOOSURE 80L Waterproof Zipper Bag

Please read this manual before using the product.




How to Mount YOOSURE Waterproof Bag on Car Roof

I. Preparations

1. Inspect the roof rack: Ensure the roof rack is securely fastened with no loose parts. The combined load capacity of the roof rack and vehicle roof must exceed the maximum weight of the waterproof bag when fully loaded.
2. Clean the roof: Remove dust and gravel from the roof to prevent friction damage to the waterproof bag's base and the vehicle's roof paintwork.

II. Installing the Waterproof Bag

1. Unfold the waterproof bag, remove the shoulder straps, and lay the bag flat on the vehicle roof. Locate the four included securing straps.
2. Thread one end of each strap through the underside of the roof rack (preferably crisscrossing for even tension distribution). Pass the end without the loop through the loop on the opposite end of the same strap, then tighten the strap.
3. Correctly thread the strap's open end through the bag's "D-ring" buckle (installation method shown below), pull downward to tighten, and ensure no slack remains.
4. The webbing straps feature a secondary safety lock. Ensure the safety lock is securely engaged before use.
5. Repeat the above steps to install all 4 securing straps. Re-inspect the waterproof bag's mounting on the roof to ensure it is firmly secured.



Safety Warning: Overloading or improper installation may cause luggage to fall off, leading to traffic accidents! Always follow the instructions in the manual!

Maintenance

Cleaning: Wipe surface stains with a damp cloth. For stubborn stains, use a neutral detergent. Do not machine wash or bleach.

Storage: Fold and store in a cool, dry place after complete drying. Avoid crushing under heavy objects.

After-sales Service

We fully comply with Amazon's after-sales service policies.

Instructions for Use

I. Roof Loading

1. Distribute weight evenly: Place heavy items at the bottom, with lighter/softer items on top, ensuring balanced weight distribution on both sides.
2. Capacity limits: Do not exceed the standard capacity (80L). Overloading may cause deformation of the bag.
3. Seal zippers: Pull zippers all the way to the end to ensure complete closure. Failure to fully seal may allow water ingress into the bag.

II. Daily Multifunctional Use

This multifunctional waterproof bag features multiple usage modes. In addition to the roof mounted installation described above, it can be carried as a backpack using the included shoulder straps (with waist belt and removable padding), lifted by the handles on both ends, or carried by hand using the detachable handle.

Notes

I. Safe Driving

1. Reduce speed on complex road conditions such as sharp curves and strong winds. Roof-mounted cargo increases braking distance; avoid sudden braking and anticipate road conditions in advance.
2. Before use, check the secure fastening of waterproof bags. Periodically stop to inspect strap tightness and bag stability.

II. Environmental Considerations

1. Heavy Rain: During downpours, cover bags with waterproof covers or add extra waterproof layers inside.
2. Strong Wind Conditions: Use additional reinforcement straps during high winds, or suspend use.

III. Prohibited Actions

1. Strictly prohibit storing flammable/explosive items or sharp objects (e.g., gas cylinders, knives).
2. Do not climb onto the roof or adjust the load while driving. Do not use it as a lifesaving device.

IV. Additional Notes

1. After installation, vehicle height increases. Be mindful of height restrictions (e.g., garage entrances).
2. When not in use, disassemble and store to prevent aging from prolonged sun exposure.
3. Increased wind resistance and noise after roof loading are normal phenomena.)

YOOSURE 80L

WATERPROOF ZIPPER BAG PACKING LIST



Yoosure Waterproof Bag




Backpack Straps



Detachable handle



Hip Belt



4x Car Roof Mount Strap



Detachable Backpack Spacer Pad

WARNING:

This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information: www.P65Warnings.ca.gov.

INSTRUCTION:

To ensure waterproof performance: Fully close the airtight zipper

Do not overload the bag beyond the stated capacity (80L), as excessive pressure may damage the waterproof seal.