

PT BANDAR BERLAYAR INTERNASIONAL
Tel: +62 21 2528 613, 614, 615, 616 | Fax: +62 21 2528 613
AOH: +62 811 1609 711 | Email: ptbbi@ptbbi.net
Website: pttbi.net



PORT INFO INDONESIA BONTANG PORT (EAST KALIMANTAN)

GENERAL INFORMATION	PONTANC COAL TEDMINAL
BERTH NAME	BONTANG COAL TERMINAL
1 . PORT INFORMATION	
* Pilot boarding ground	: Lat. 00-00-00 Long. 117-35-00 E
* Anchorage area	: Lat. 00-00.5 N Long. 117-35-00 E
* Berth position	: Lat. 00-01-57 N Long. 117-32-02 E
* Annual Capacity	: 18 million tones
* Working hours	: 24 hours perday, 7days per week except in National Holidays
* Coal Stowage Factor	: 42,0 CUBFT / MT
* Draft Survey	: Independent surveyors
* Density of water	: At all times 1019 to 1023
* Navigational chart	: British BA No. 3040, Indonesia Hydral No. 39, 39A
* Standard Time	: UTC + 8 Hrs
* Communication	: By VHF on CH 71 and CH 16 (Agent/Pilot/Terminal)
2. COAL RECEIVING	
* Number of Truck Dumps	: 4
* Unloading Rate	: Dump Bin 1 & 2 2 x 1,500 tph
·	Dump Bin 3 1 x 1,200 tph
	Manual Dump 1 x 600 tph
* Max. Barge Size at CBU	: Width 28 m, Length 100 m
* Unloading Rate	: 1 x 4,000 tph
* Unloading Option	: To stockpile or directly to vessel
3. STOCKPILING	
* Number of Stockpiles	: 13
* Working Capacity	: 320,000 tonnes
* Work Capacity	: 240,000 tonnes
* Stacking Rate	: Twin Boom Stacking 1 x 2,000 tph
	: Tripper Conveyor 1 x 3,000 tph
* Stockyard Equipment	: 6 bulldozers
4. COAL RECLAIMING	
	: Reclaim Feeders 7 x 1,500 tph
* Reclaiming Rate	: Reclaim Feeders 6 x 3,000 tph
	: Shiploader Capacity 1 x 3,600 tph
	. Onlipidadei dapadity 1 x 0,000 tpii
5. TURNING BASIN	
* Location	: West Southwest of light beacon " C " with
Location	coordinates Lat. 00-02-22 N Long. 117-32-16 E
* At berth	: 14,5 mtrs
* Turning basin	: 14,5 mtrs
* In the channel	: 14,5 mtrs
6. BERTH	
* Type	: Wharft / Dolphin
* Berth Space	: 1 Vessel
* Max. Vessel Size	: 95,000 DWT
* LOA	: 250 mtrs
* Beam	: 43 mtrs
* Draft of Departure	: 13,5 mtrs
* Jetty length	: 158 mtrs
* Length between dolphins	: Min. 50, Max. 57 mtrs
* Number of Dolphins	: 5
* Depth	: 14,5 mtrs : Mud
* Nature of seabed	
* Which Side Alongside to	: At BoCT berths vessel are normally berthed and loaded Starboard Side Alongside to the wharf / jetty.
	StarDuard Side Alongside to the what / Jetty.
7. WEATHER CONDITION	
* Dry Season	: May to August
* Wet Season	: September to April
* Prevailing wind	: Southest to Northeast Direction
* Fog / Smoke	: Min. Visibility distance required for berthing 2 miles
-	
8. TIDAL STREAM	
* Direction	: Southeast to Northeast
* Velocity	: 2 Knots
9. AA. LOADING FACILITY BY SHORE LOADER	
* Shiploader Type	: Quadrant luffing boom
* Outreach from fender edge	: 32 mtrs + banana spout = 7 mtrs
* Travelling distance	: 104,0 mtrs
* Max. loading rate	: 3500 tph
* Airdraft	: 16,5 mtrs

PT BANDAR BERLAYAR INTERNASIONAL

Tel: +62 21 2528 613, 614, 615, 616 | Fax: +62 21 2528 613 AOH: +62 811 1609 711 | Email: ptbbi@ptbbi.net Website: pttbi.net



BB. LOADING FACILITY BY FTS

* LOTUS 668 : 2 units of hydroulic grab bucket discharge coal from a barge

with capacity load is 1,300 Mt/Hours.

10. BALLAST PUMP OUT AS TERMINAL REQUIRED

: For vessel loading use FTS min required for ships pumping ballast is 2,000 Mt/Hrs to follow conveyor load capacity for avoid ship stresssing and ship stability problem.

11. TUG BOAT

* No. Of Tugs : 3 Units

* House Power : 2 x 4,000 HP, 1 x 3,000 HP
* Bollard Pull : 50 tons and 20 tons

12. PILOTAGE / COMPULSORY

* Pilot : 3 Persons

* Embarking Point : Lat. 00-00-00 S, Long. 117-35-00 E

* Communications : By VHF on CH 71 and CH 16, thru Wilhelmsen Bontang

* Restricted Hours : Between Sunset and Sunrise

13. RESTRICTIONS OF BERTHING/UNBERTHING OPERATIONS:

* Wind Force Max : 15 Knots * Wave Height : 2,5 Mtrs * Current : 2 Knots

* Berthing/Unberthing Time : 24 Hours (Sub AGW.WP)

14. RESTRICTIONS OF LOADING OPERATIONS:

* Max. Wind Force : 20 Knots

* Wave Height : 2 Mtrs

* Current : 4 Konts

15. VESSEL ALONGSIDE WITH MOORING LINES ARRANGEMENT AS FOLLOW:

 * 4
 Head lines forward to
 MD 6

 * 4
 Astern lines after to
 MD 1

 * 2
 Breast lines forward to
 MD 5

 * 2
 Breast lines after to
 MD 2

 * 2
 Spring lines forward to
 BD 2

 * 2
 Spring lines after to
 BD 3

16. BUNKER, FRESH WATER : NOT AVAILABLE

17. CREW PASSPORT

* Immigration will charge penalty for passport which validity less than 6 months

* Crew passport should valid more than 6 months

Security Information

Port Security Level :

Port Security at BoCT is LEVEL 1 (ONE)

PFSO Information :

Coordinator of ship and Port security committee (Harbour Master)

Phone: +62 548 21568

Port Security Officer : Mr.Indra Pramana Gustu

Phone +62 548 26235 Ext. 1540

Fax +62 548 26241

Mob +62 813 4786 8790

Email indra_g@banpuindo.co.id
Deputy Port Security Officer:

Mr.Parada Sihite

Mob : +62 811 580 263

The details of Harbour Master Bontang full style as follows :

Harbour Master / Kanpel Tanjung Laut Bontang

Jl. Pelabuhan No. 28

Tanjung Laut - Bontang 75321 East Kalimantan - Indonesia

PIC : Mr. Adrifan

OTHER USEFUL INFORMATION

LOCAL TIME : GMT + 8 HOURS

WHEATHER CONDITION : RELATIVE HUMIDITY 99% WITH VISIBILITY 8 KM, PRECIPITATION RAIN 9 1/m2 LAST 24 HRS,

TEMPERATURE 24°C / 75°F

WORKING HOURS : 24 HOURS/DAY, 7 DAYS/WEEK SHINC, EXCL. NATIONAL MAJOR HOLIDAY
TYPE OF TERMINAL : PUBLIC TERMINAL

ALL INFORMATION ABOVE PROIVIDED IN GOOD FAITH BY BBI AGENCY.

WE ACCEPT NO LIABLTY FOR INACURATE INFORMATION

BBI AGENCY - AS AGENTS ONLY