



HARD CASE GOLF TRAVEL BAG

USER MANUAL

Travel Safely With Your Golf Equipment





USER MANUAL

This user manual is intended to provide comprehensive guidance and instructions for the safe and effective use of RIVOX Golf Travel Bag. It is designed to assist users in understanding the features, functionalities, and proper operation of the product. By following the instructions outlined in this manual, users can optimize their experience and ensure the longevity of the product.

Please read this manual carefully before using RIVOX Golf Travel Bag to familiarize yourself with its operation, maintenance requirements, and safety precautions. Failure to adhere to the guidelines provided in this manual may result in injury, damage to the product, or voiding of the warranty.

The information presented in this user manual is accurate and up-to-date to the best of our knowledge. However, as technology and product specifications may evolve over time, we reserve the right to update or revise this manual without prior notice.

If you have any questions, encounter difficulties, or require additional assistance while using RIVOX Golf Travel Bag, please refer to the relevant sections of this manual or contact our customer support team for prompt assistance.

Thank you for choosing RIVOX. We trust that this user manual will enhance your experience and help you make the most of our product. Happy travel!



SUPPORT ROD

Designed to provide stability and protection to your golf bag during travel.

Step 1. Lay out all components included in the package.

Step 2. Fit the ABS anti impact cover using the threaded bolt on the underside of the cover, screw clockwise into the threaded nut insert on the end of the rod.

Step 3. Ensure all connections are tight and secure before use.

Step 4. Adjust the length of the support rod sections to your required height and lock the button clips in place in the desired button hole to suit.

Step 5. Place the the support rod inside your golf bag above the height of the longest club to ensure the rod sustains any impact first, that may occur from the top.

Step 6. Ensure the height and angle of the support rod is adjusted as required to ensure proper alignment and stability.

Step 7. Close your golf bag, ready to place inside the RIVOX golf travel bag.

RIVOX HARD CASE GOLF TRAVEL BAG

Opening RIVOX golf travel bag for use.

Step 1. Lay the bag on the floor and open the dual zippers so the front flap folds down fully.

Step 2. Place your golf bag with clubs inside ensuring the base is centred on the bottom of the travel bag base.

Step 3. Adjust the internal strap to required length and secure the strap around the golf bag and lock the clips in place. Check to ensure there is no movement in the golf bag and the bag is secured properly.

Step 4. Check the height of the support rod to ensure this is at suitable length for any impact.

Step 5. Zip up the dual zippers on the front of the golf bag and close fully.

Step 6. Stand up the golf travel bag onto the base upright, adjust and secure the external securing strap around the ABS hard top shell and lock the clips in place.

Step 7. Add padlock to the heavy duty zipper to secure travel and make it safe.



TSA PADLOCK

How to change TSA Padlock combination numbers.

- Step 1.** The original password is "0-0-0" to open the padlock.
- Step 2.** Push up the latch hook and turn 180 degrees.
- Step 3.** Once in the 180 degree position push down on the latch hook and change to the new passcode desired.
- Step 4.** Once changed to desired code pull up the latch hook and rotate back 180 degrees to normal position.
- Step 5.** Your new passcode is now set and ready for use.



MAINTENANCE & CARE

- **CLEANING** – regularly clean your golf bag to prevent dirt and grime from building up. Use a damp cloth to wipe down the outside of the bag and any pockets or compartments. Be sure to wipe the bag dry after cleaning to prevent mildew or mold from forming.
- **DRY IT OUT** – If your golf bag gets wet, either from rain or from cleaning, make sure to dry it out thoroughly. Leave the pockets open and the bag in a well-ventilated area to dry.
- **STORAGE** – When not in use, store your bag in a cool, dry place, away from direct sunlight. Extreme temperatures and sunlight can damage the bag. For best storage store in the collapsible position with the lower nylon section folded and placed inside the hard top shell with the wheels at the bottom.

SAFETY

Proper Handling: When transporting the RIVOX golf travel bag, handle it with care to avoid dropping or mishandling, which can cause damage to both the clubs and the bag itself. Additionally, be mindful of weight distribution across the bag to prevent any strain or damage to the bag's handles or zippers.

Avoid Overpacking: Don't overstuff your RIVOX golf travel bag with unnecessary items. This can put strain on the bag and increase the risk of damage to your clubs.





CONTACT US



www.rivoxsports.com



support@rivoxsports.com

