

Electronic Device Technical Data Sheet

WHAT AND HOW TO SPRAY ELECTRONIC DEVICES

	Smartphone open back	Smartphone sealed	Power bank charger	Camera	Drone	Bluetooth headset	РСВ	Smartwatch
On/off button	V	~	~	~	~	~	V	~
Charging/discharging port	V	V	~	>	~	V	V	V
Volume button +/-	V	V	-	>	-	V	-	V
Microphone jack	V	V	-	>	V	V	-	V
Battery	V	-	~	~	V	~	V	-
Speaker	V	V	-	~	-	~	-	V
Micro/USB outlet	V	V	~	~	V	-	-	V
SIM card/SD card	V	V	-	~	V	-	-	V
Camera lens/screen/monitor	X	×	-	×	X	-	-	×
Flashing light	X	×	X	X	X	×	-	×

[✓] a spray lightly for 2 seconds from a distance of 10 cms, for best protection do not wipe off solution, works best when a thin layer remains on the electrical parts, be careful to not touch the electrical parts, wait for 15 minutes after spraying before powering on your device, we recommend once every 6 months maintenance spray on the ports subject to wear and tear.

Designs and models of above electronic devices may vary

Please refer to http://www.zoemspray.com/en#faqs for terms of business

x do not spray

⁻ not applicable to this device