


CLEANING PROCEDURE AURELIA WAVE VOL

<p>1) Press the washing button for 3 seconds.</p>	
<p>2) The continuous buttons of the groups will start flashing; press that button to start the cleaning procedure.</p>	
<p>3) If the groups are cleaned separately, it is possible to use the other groups returning to the main menu by press the washing button  or waiting 20 seconds.</p>	
<p>4) At the end of the washing cycle, the continuous buttons will start flashing again and it will be possible to activate the rinse cycle. Before and during rinsing, the machine indicates the chosen group number + R; as long as the rinsing procedure is not carried out entirely, the group is blocked.</p>	
<p>5) At the end of rinsing, return to the main menu by successive touches on the sidelines </p>	