

Please Read before Cutting

The .CNC files in this folder were post processed as using a 0.8mm tip on the plasma torch. If the torch you have or will be using is not 0.8mm then you will need to set the kerf width on the plasma table manually instead of using the kerf width programmed into the file. Using a kerf width unsuitable for your tip will result in incorrect part/model sizes when cutting.