

Settings for Lightning Stitch Regulator to Baste Your Floating Quilt Top

TIP If you ever see a red "X" in the upper-right corner, don't panic! This exits the quilting interface and accesses the computer's operating system. If pressed by mistake, simply turn your machine off and back on to reboot.

CRUISE (circled in red)

NOT (circled in red)

CRUISE (circled in red)

CRUISE (circled in red)

NEEDLE (circled in red)

NEEDLE POSITION: Up or Down?
Do you want your needle to stop up or down when you pause quilting?
NEEDLE Up (circled in red)
NEEDLE Down

CRUISE (circled in red)

Blue is Manual

Gray is Regulated

Stitch Controls
With a single tap, you can switch between different stitching modes
BLUE indicates the current selection

SPI for Current Selection
Manual Mode
Basting Mode
Stitch Regulated Presets

CRUISE is GRAY (REGULATED)

Needle is UP

2nd Stitch Preset Highlighted

LASER LIGHT
Toggle ON/OFF for precision guidance

LED Light Control
Switch between Bright, Dim, Black Light, or OFF
Bright Light
Dim Light
Black Light
OFF

TIE
Secures stitches at the beginning and end of quilting. You can set the number of stitches for this function in the Settings Screen. This number will display under the TIE button.

Displays the estimated percentage of bobbin thread remaining.
Click to reset the counter when replacing the bobbin. Adjust the value as needed. An initial value of 100-120 is a good place to start.

Tracks how long your machine has been running.
Click to reset the timer to zero.

Counts every stitch
Click to reset the counter to zero between quilts.

PICK UP
Brings up the bobbin thread with one full needle rotation.

Settings for Lightning Stitch Regulator to Quilt Your Quilt

TIP If you ever see a red "X" in the upper-right corner, don't panic! This exits the quilting interface and accesses the computer's operating system. If pressed by mistake, simply turn your machine off and back on to reboot.

CRUISE


CRUISE

NOT

Gray is Regulated

Blue is Manual

CRUISE



Stitch Controls
With a single tap, you can switch between different stitching modes. BLUE indicates the current selection.

- SPT for Current Selection
- Manual Mode
- Basting Mode
- Stitch Regulated Presets

Cruise is GRAY (REGULATED)

Needle is UP

4th Stitch Preset Highlighted

NEEDLE POSITION: Up or Down?
Do you want your needle to stop up or down when you pause quilting?

NEEDLE UP

NEEDLE DOWN

NEEDLE UP

LASER LIGHT

Toggle ON/OFF for precision guidance.

LED Light Control

Switch between Bright, Dim, Black Light, or Off

Bright Light

Black Light

Dim Light

OFF

Displays the estimated percentage of bobbin thread remaining.
Click to reset the counter when replacing the bobbin. Adjust the value as needed. An initial value of 100-120 is a good place to start.

Tracks how long your machine has been running.
Click to reset the timer to zero.

Counts every stitch
Click to reset the counter to zero between quilts.

PICK UP
Brings up the bobbin thread with one full needle rotation.

TIE
Secures stitches at the beginning and end of quilting. You can set the number of stitches for this function in the Settings Screen. This number will display under the TIE button.