ONNY MARLIN

BONNY MARLIN SYSTEM® INSTALLATION INSTRUCTIONS

The Bonny Marlin Paint Gun Cleaner is 33" wide without optional shelf and 41" wide with shelf. The left side of unit has two filters that need to be changed for maintenance. In order to avoid having to pull the unit out from the wall for maintenance, we suggest providing a foot of clear space on the left side.

In order to create an efficient working environment, we suggest placing the unit in or near the paint mixing room.

The system is powered by shop air. An airline hose with a ¹/₄ inch male threaded end is provided on the Bonny Marlin cleaning station. The shop needs to provide a female airline connector compatible to shop air supply hose.

No electrical service is needed.

The Bonny Marlin solution is a low VOC cleaner. No venting is typically required

INSTALLATION STEPS:

- 1. Attach air line connector to hose.
- 2. Attach Leg Levelers.
- 3. Place unit in location where it will be installed.
- 4. Attach GREEN WIRE to grounded surface.
- 5. Put residue restrictor (small, thick metal plate with hole) over basin bottom drain hole and screw in drain mushroom screen.
- 6. Insert flat rubber washers at each end of <u>**Recycle filter**</u> (the one with plastic ends) and place in blue housing.
- 7. Install O ring in top of blue housing.
- 8. Install housing hand tight on **<u>REAR</u> black** filter housing top under skirt below control panel.
- 9. Insert white <u>**Pre-Filter**</u> (string wound) in other blue housing.

- 10. Insert O ring in top of blue housing.
- 11. Install housing hand tight in **FRONT** black filter housing top under the skirt below control panel.
- 12. Close basin drain valve and fill basin with Bonny Marlin Solution up to base of screen support bracket on side of basin.
- 13. Place screens in basin
- 14. Turn off all control valves. (Pointed to the right)
- 15. Connect air to system.
- 16. Adjust air pressure to **<u>80 lbs</u>**
- 17. Turn on MAIN CONTROL VALVE in front of control panel.
- 18. Open remaining valves slowly.
- 19. Check system for leaks.
- 20. The new recycle filter may take 10 minutes to saturate and allow fluid flow.
- 21. Turn off all valves, **including** recycle valve at back of control panel.

System is ready for operation!!

The Bonny Marlin solution works by stripping paint off of the gun. Your used paint guns must be initially thoroughly cleaned using the Bonny Marlin System before you start painting. If you don't, you may experience occasional "spitting" as old paint particles are gradually removed. Break down and thoroughly clean all used paint guns.

Whenever the system is not in use, keep the MAIN OFF/ON valve OFF. This will prevent a solution spill if ever a hose slips off.

If you have any questions, please feel free to contact

Bonny Marlin at 888 962-7546.

Copyright 2005 Bonny Marlin Inc.