

GMRS Radio Instructions

Radio Group

A

Channel 01



Attach Battery Pack to back of radio

TURN ON/OFF: Turn knob. Channel number is announced. Adjust Volume

CHANGE CHANNEL: Turn knob to display assigned channel.

TRANSMIT: Push and HOLD top button on left side of radio. Wait ONE SECOND before talking. Hold Radio upright a few inches from your mouth RELEASE button when you finish talking.

STAY CALM

SPEAK CLEARLY

**MAKE SURE YOUR MESSAGE
HAS BEEN RECEIVED ACCURATELY**

If you cannot communicate, ask if anyone can hear you. Relay your message through them, otherwise go to another AID Station and have them report for you.

