

### **Making your Bulb Blink**

1. If your bulb is not blinking when it is first installed, you must set it to pair mode.
2. To do this, you will need to switch your bulb, on-off-on-off-on.
3. Once it starts blinking, it is now ready to be paired with your Genio App.