


Empava 12" Electric Induction Cooktop With 2 Burners

Smooth Surface Black Vitro Ceramic Glass EMPV-IDC12

1. **Cookware Specifications:** The cookware has to be Induction friendly mostly magnetic material like (Cast-Iron, Stainless Steel). ***Aluminum cookware will not work.***
2. Once you have placed the cookware with food on the stovetop. touch the power and choose the particular burner you want to use.



- 1) **Hot Surface indicator - An "H"** will appear in the surface cooking area display as long as any surface cooking area is too hot to touch, even after the surface cooking area(s) is turned off. With induction cooking, heat is generated directly in the cookware, so the cooktop stays cooler to the touch, with child safety lock making it safer.
- 2) Sensors detect the presence of a pan, so when a pot is removed and the element is still on, the cooktop will automatically turn off.
- 3) **Lock release: Display shows "Lo"**, this will lock all touch buttons. Keep the lock button touched 5-10 seconds to release the lock.