Network/Phone Equipment Quick Tips and Instructions

Internal Dialing Rules

Extensions: 101-115
Page all extensions: 000
Call all extensions: 100
Access Voicemail: 200

External Dialing Rules

National 10 Digit Dialing (xxx) xxx-xxxx Service Numbers: x11 (e.g. 411, 911, and etc)

Equipment

1. Call Manager Express Voice Router

Hostname: CME_RT

2. Call Manager Express Voice Switch

Hostname: CME_SW 3. Phones

Warning

Do NOT Install the networking equipment Near Water, hot temperature or dusty areas. Plug into a surge protector or a battery backup UPS. Never use a surge protector between a device, and the UPS.

Network Connections

Connect POTS Lines to FXO ports from Right to Left.
Connect GEO/O To the indicated Uplink Port on the CME_SW.
Connect a WAN or an additional LAN Port To GEO/1. (This port is used for CME_RT, CME_SW management, and system clock Synchronization.)

Contact Information

Swipe Call, Inc. DBA nthere

Phone: (818) 855-8827 Email: contact@nthere.com URL: https://nthere.com