

FINAL CHECK LIST



- ☐ Double check the tent poles are secure in the eyelets.
- ☐ All stakes are secured into the ground.
- ☐ Rainfly is securely attached to rings.

Enjoy your new
World Famous Sports tent.



For any questions or concerns please call our toll free customer service line.

WORLDFAMOUSSPORTS.COM

(833) 937-1234
(833) WFS-1234



INSTRUCTION MANUAL
MODEL #:730

IMPORTANT

Treat your tent seams with waterproofing. Set up your tent at home before your first camping trip. A dark campsite is no place to learn how to assemble your WORLD FAMOUS SPORTS tent. Read assembly instructions with care. When selecting a campsite, make sure you find a flat area with good drainage free from all sharp objects. Protect your investment.








This product can expose you to chemicals including Diethylhexyl Phthalate, which is known to the state of California to cause cancer, birth defects, or other reproductive harm. For more info go to: [www. P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)


PARTS

PARTS IDENTIFICATION:


- A. Tent(1)
- B. Rainfly(1)
- C. Shock Corded Fiber Glass Poles.. (2 shorter/ 2 long poles)
- D. Tent Stakes (10)
- E. Mudflap (1)




ASSEMBLY





STEP 1: Unfold and spread the tent out on clear camp area. Remove all stones and sharp objects.





STEP 2: Assemble all shock corded poles by unfolding and slipping shafts together.




STEP 3: Lay the two longer poles across the tent to form an "X" across the tent. (If your tent comes with sleeves, run the assembled pole sections through the sleeves before attempting to erect the tent).




STEP 4: Insert the pin and ring attached on the corner of the tent into the open metal ferrule at the end of the pole assembly, **Repeat for all four corners.** In repeating the procedure, you have now formed two arches.





STEP 5: Fasten the tent clips to the pole assembly for further security.




STEP 6: Tie the two arched pole assemblies together with the ties at the top of the tent.



STEP 7: Insert the two shorter "Ridge Pole" assemblies into the pockets of both sides of the rain fly cover. Executing this step will form the poles into a "+" shape when complete. Then spread the rainfly over the top of the tent.



STEP 8: Each corner of the rainfly has a bungee cord with plastic "S" hooks - Attach each "S" hook to tent's pin and ring.



STEP 9: Securely insert tent Stake into the ground through the small pin and ring on each corner of the tent and middle of bottom.