

SOLAR PRO 200Zb TW/CW

USER MANUAL

200W LED 25-50°zoom profile light



Operate instruction

Package and accessories

- 1. 200W LED zoom profile light25-50 $^{\circ}$ 1 unit
- 2. 3 pin signal connector 1 pair
- 3. Power plug 1 pair

• Functions •

- ♦ Input voltage 100-240V 50-60HZ
- ◆ Power consumption 220W
- ◆ Manual zoom
- ◆ Zooming scale : 25-50°
- ◆ DMX dim or manual button dim
- ◆ 16 bit above no flicker linear dimming
- ◆ Inner size: 76×28.5×28.5cm◆ G.W.: 14kg N.W.: 12kg

Keys instruction

- ◆ Press Function key display different functions cyclically .
- Press decrease key and increase key to adjust each function's value.
- ◆ Press confirm key to confirm the function and value .

Special remind: when the multi units power cable mutual input / output connected ,each group can connect10 units, power cable must use 3×2.5^2 grounding .

Screen display and its function

Screen display and its junction		
No.	Screen	Function instruction
1	DMX-ADR	Already connect with DMX wire. press "Q" and "D" keys can adjust address.
	001 V	
2		.
	DMX-ADR	not connect with DMX wire. Can set master/slave connected, press "Q" key or "D" key can adjust address yo
	001 X	want.
3	ADJ-CW	.aa.
	255	Enter manual button dim mode press "①" key and "Û"key to dim
4		Prior for DMX, press 1 "or " 1 " choose the function DMX SING ON/OFF, and ten press 2 to save/confirm the
	DMX SING	Prior for DMX, press or "or "or "choose the function DMX SING ON/OFF, and ten press to save/confirm the
	OFF/ON	function
5		
	DMX KEEP	for DMX keep/off, press ① "or " Û " choose the function you want, and ten press c to save/confirm the function
	OFF/ON	

• DMX channels functions •

Only 1 DMX channel 0-255 dim

• Master/slave connect introduce •

Set all units address same as "001", off DMX signal, can set any unit as master, set functions on the master unit by the Function key all units are synchronal