# SOLAR PRO 200Za TW/CW

USER MANUAL

200W LED 15-30°zoom profile light

Operate instruction

• **Package and accessories** •

1. 200W LED zoom profile light15-30° 1 unit
2. 3 pin signal connector 1 pair
3. Power plug 1 pair

• **Functions** •

◆ Input voltage 100-240V 50-60HZ
◆ Power consumption 220W
◆ Manual zoom
◆ Zooming scale : 15-30°
◆ DMX dim or manual button dim
◆ 16 bit above no flicker linear dimming
◆ Inner size: 86×28.5×28.5cm
◆ Packing size: 99×30.5×31.5cm
◆ G.W.: 15kg   N.W.: 13kg

• **Keys instruction** •

⌂→ Confirm   ⬌→ Function   ⬇→ Decrease   ⬆→ Increase

◆Press Function key display different functions cyclically .
◆Press decrease key and increase key to adjust each
   function's value .
◆Press confirm key to confirm the function and value .

Special remind: when the multi units power cable mutual input / output connected ,each group can connect10 units, power cable must use 3×2.5^2 grounding .

• **Screen display and its function** •

No.	Screen	Function instruction
1	**DMX-ADR** **001 V**	Already connect with DMX wire . press "⬇"and "⬆" keys can adjust address.
2	**DMX-ADR** **001 X**	not connect with DMX wire. Can set master/slave connected, press "⬇" key or"⬆" key can adjust address you want .
3	**ADJ-CW** **255**	Enter manual button dim mode press "⬇" key and"⬆"key to dim
4	**DMX SING** **OFF/ON**	Prior for DMX, press ⬇ "or "⬆" choose the function DMX SING ON/OOF , and ten press ⬌ to save/confirm the function
5	**DMX KEEP** **OFF/ON**	for DMX keep/off, press ⬇ "or "⬆" choose the function you want , and ten press ⬌ to save/confirm the function

• **DMX channels functions** •

Only 1 DMX channel 0-255 dim

• *Master/slave connect introduce* •

Set all units address same as "001" , off DMX signal , can set any unit as master, set functions on the master unit by the Function key all units are synchronal