

Master Trac Hang Mount System Parts and Installation



Call us at 1-855-854-7465

or vist us at

www.sauder-closets.com

NOTE: THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION.


PLEASE READ AND KEEP FOR FUTURE REFERENCE.




Lot #: 573359 03/21/22 Date Purchased:

Table of Contents

Part Identification	3-9
Hardware Identification	9-11
Hardware Usage Guide	12
Hang Cabinet Installation	13-29
Door Installation	30
Drawer Installation	31-32
Shoe Shelf Installation	33
Closet Rod Installation	34
Adjustable Shelf Installation	35
Adjustable Shelf Cut Installation	36
H-Joint Channel Istallation	37
Bracket Kit Installation	38
Hole Boring and Jig Installation	39
Cleat Dowel Boring Jig Installation	40
Cabinet Hanger Cover Installation	41
Weight Limits	42
Safety	43
Warranty	43






Page 4

Fixed Corner Shelf 432556 White 430833 Slate Rift 432786 Spice Mahogany



(Actual 291/4" x 291/4")

Adjustable Corner Shelf 432557 White 430834 Slate Rift 432787 Spice Mahogany



(Actual 29¹/₄" x 29¹/₄")

18" Shoe Shelf 432558 White 430870 Slate Rift 432788 Spice Mahogany



(Actual 18" x 14\%")

24" Shoe Shelf (1) 432559 White 430871 Slate Rift 432789 Spice Mahogany



(Actual 24" x 14\%")

30" Shoe Shelf 432560 White 430872 Slate Rift 432790 Spice Mahogany



(Actual 30" x 143/8")

18" Shoe Fence 432926 Matt Nickel 432925 Polished Chrome



24" Shoe Fence 432927 Matt Nickel 432928 Polished Chrome



30" Shoe Fence Matt 432929 Matt Nickel 432930 Chrome



18" Small Drawer Front 432567 White 430847 Slate Rift 432797 Spice Mahogany




(Actual 18½" x 4½")

24" Small Drawer Front 432568 White 430848 Slate Rift 432798 Spice Mahogany



(Actual 245/8" x 47/8")

30" Small Drawer Front 432569 White 430849 Slate Rift 432799 Spice Mahogany



18" Large Drawer Front Slab 432570 White 430853 Slate Rift 432800 Spice Mahogany



(Actual 181/2" x 97/8")

24" Large Drawer
Front Slab
432571 White
430854 Slate Rift
432801 Spice Mahogany



(Actual 245/8" x 97/8")

30" Large Drawer Front Slab 432572 White 430855 Slate Rift 432802 Spice Mahogany



(Actual 30½" x 9¾")

18" Large Drawer Front Shaker 432573 White 430856 Slate Rift 432803 Spice Mahogany




(Actual 181/2" x 97/8")

24" Large Drawer Front Shaker 432574 White 430857 Slate Rift 432804 Spice Mahogany




(Actual 245/8" x 97/8")


30" Large Drawer Front Shaker 432575 White 430858 Slate Rift 432805 Spice Mahogany




(Actual 30½" x 9½")

www.sauder-closets.com







432386-30" Small
Drawer Assembly
430843 Drawer box only
432384 Hardware only




432387-18" Large Drawer Assembly 430844 Drawer box only 432384 Hardware only




432389-24" Large Drawer Assembly 430845 Drawer box only 432384 Hardware only



432390-30" Large Drawer Assembly 430846 Drawer box only 432384 Hardware only




24" Coat Hook Board 432613 White 432035 Slate Rift 432843 Spice Mahogany



(Actual $5\frac{1}{2}$ " x $23\frac{7}{8}$ ")

18" Coat Hook Board 432612 White 432034 Slate Rift 432842 Spice Mahogany



(Actual 5½" x 17%")


Hamper Kits

432604 White 24" Slab Door 432602 White 24" Shaker Door 432605 White 30" Slab Door 432603 White 30" Shaker Door 431874 Slate Rift 24" Slab Door 430875 Slate Rift 24" Shaker Door 431875 Slate Rift 30" Slab Door 430876 Slate Rift 30" Shaker Door 432834 Spice Mahogany 24"Slab Door 432835 Spice Mahogany 24" Shaker Door



Crown Molding (classic) 432601 White 430874 Slate Rift 432831 Spice Mahogany Crown Molding (shaker)

432600 White 430873 Slate Rift 432830 Spice Mahogany



Parts Identification and Hardware Identification

Shelf Cam

433145 White (2500)

433148 White (250)

433151 White (25)

433146_Bronze (2500)

433149 Bronze (250)

433152 Bronze (25)

433147_Brown (2500)

433150 Brown (250)

433153 Brown (25)



Push-In Dowel 433154 (5000)

433155 (250) 433156 (25)



Screw-In Dowel 433157 Steel (4500) 433158 Steel (250)

433159 Steel (25)

Double Dowel 433163 Steel (3000) 433164 Steel (250) 433165 Steel (25)



Bracket only 433200 White (250)


433201 Brown (250)

433202 Black (250)




Bracket Kit 433203 White (10)


433204 Brown (10) 433205 Black (10)



Toggle Anchor 431220





Extension Rail Template Kit




Corner Shelf


H-Joint Channel








Cam Jig Install Kit 433170 Zinc



Adjustable Shelf Template 433926 White




Rolled Edge Banding 429614 White

432854 Slate Rift 432855 Spice Mahogany



2-3/4" Flat Head Screw 433179 (250) 433180 (25)




5/16" Euro Screw 433182 (250) 433183 (25)




5/8" Flat Head Screw 433378 (250) 433377 (25)



Hinge Kit 432396 (6 hinge pack) 432397 (8 hinge pack)




Hardware Identification




Rod Cup 432933 Matt Nickel (200) 432934 Matt Nickel (10) 433224 Chrome (200) 433225 Chrome (10)



Curved Oval Rod Kit 433701 Steel (1)





Shelf Support 432935 (500) 432937 Nickel (50)



<u>Left Cabinet Hanger</u> 433129 (200) Zinc 433131 (1) Zinc




Left Cabinet Hanger Cover 433133 (50) White 433139(1) White 433135 (50) Black 433141(1) Black 433137 (50) Brown 433143(1) Brown



Right Cabinet Hanger 433130 (200) Zinc 433132 (1) Zinc



Right Cabinet Hanger Cover 433134 (50) White 433140(1) White 433136 (50) Black 433142(1) Black 433138 (50) Brown 433144(1) Brown



Contemporary Pull 433189 Brushed Nickel 433190 Polished Chrome 433191 Matt Gold 433192 Matt Black 433193 Matt Chrome




433194 Polished Chrome 433195 Matt Black 433196 Brushed Brass 433197 Stainless Steel




Knob 433184 Matt Nickel 433185 Slate 433186 Polished Chrome 433187 Matt Gold 433188 Matt Aluminum




Applique 5 Pack 432856 White 432857 Slate Rift 432858 Spice Mahogany




Hardware Identification




Hardware Usage Guide




Page 12




Hang Cabinet Hardware Preparation




In pages 14-29 we will be building the carcus of the Sample view configuration. Refer to the Table of contents for specific applications necessary to complete your installation of Hardware, Doors, Drawers, Closet Rods, Adjustable Shelves, modifying Fixed Shelves and Cleats.



Hang Cabinet Hardware Preparation





Cut a Wall Rail and Wall Rail Cover to size


NOTE: Use a 2-3/4" Flat Head Screw in every stud.

IMPORTANT: Every Cabinet Upright must be fastened within 4" of a wall stud or add a Toggle Anchor if needed.

Diagram #3


The Toggle Anchor requires 1/2" hole in the drywall. Push the Toggle Anchor into the hole, slide the SLEEVE to the drywall and break off the Tabs of the Toggle Anchor. Use the screw supplied with Toggle Anchor to secure the Wall Rail where needed.

After the Wall Rail is secured to the Wall, place a Wall Rail Cover over it. See Diagram #4 for orientation.




All Uprights require a Left or Right Cabinet Hanger.

Fasten Cabinet Hangers to all Uprights using a 5/8" Flat Head Screw. Use a Left or Right Cabinet Hanger in the least conspicuous location depending on your Design.



Hang Upright #1 onto the Wall Rail and fasten it to the side wall using three 2-3/4" Flat Head Screws into wall studs. Use three Toggle Anchors with the 3" Machine Screw. if a wall stud is not available. Reference Diagram #3 steps on page 17 showing how to use the Toggle Anchor.




Hang the Upright #2 onto the Wall Rail. Wall Cleats come with pre-glued dowels installed. Fasten a Wall Cleat to the Uprights by pushing the wood dowels in the Wall Cleat into the Uprights.

Important: A Wall Cleat is required between all Uprights taller than 48".


Note: Wall Cleats will be anchored to the wall after all Uprights and Fixed Shelves are hung on page 29.

Turn four Screw-in Dowels into the top holes and bottom holes of the corner Upright #1. Turn additional Screw-In Dowels into the holes as shown in Diagram #6 for placement of the Fixed Shelves.




Insert six Double Dowels completely into the holes in Upright #2 per the Design. Fasten three Fixed Shelves to the Uprights #1 and #2. Tighten twelve Connectors.

Turn the adjusting screws on the Cabinet Hanger to level and plumb the Upright.



Hang Upright #3 onto the Wall Rail. Wall Cleats come with pre-glued dowels in them. Fasten a Wall Cleat to the Uprights by pushing the wood dowels in the Wall Cleat into the Uprights.


Important: A Wall Cleat is required between all Uprights taller than 48".



Insert four Double Dowels completely into the holes in Upright #3.


Insert two Push-In Dowels into the left most Upright. Fasten the Fixed Shelves to Uprights #2 and #3 Tighten twelve Connectors.

Turn the adjusting screws on the Cabinet Hanger to level and plumb the Upright.



Hang Upright #4 onto the Wall Rail. Wall Cleats come with pre-glued dowels in them. Fasten a Wall Cleat to Uprights #3 and #4 by pushing the wood dowels in the Wall Cleat into the Uprights.


Important: A Wall Cleat is required between all Uprights taller than 48".



Insert four Double Dowels completely into the holes in Upright #4.

Fasten the Fixed Shelves to Uprights #3 and #4. Tighten eight Connectors.

Turn the adjusting screws on the Cabinet Hanger to level and plumb the Upright.




Hang Upright #5 onto the Wall Rail.

Insert six Double Dowels completely into the holes in Upright #5.

Fasten the Fixed Shelves to Uprights #4 and #5. Tighten twelve Connectors.

Turn the adjusting screws on the Cabinet Hanger to level and plumb the Upright.

Important: A Wall Cleat is required between all Uprights taller than 48".




Hang Upright #6 onto the Wall Rail.

Insert two Double Dowels completely into the holes in Upright #6.

Insert two Push-In Dowels into Upright #6. Fasten the Fixed Shelves to the Uprights #5 and #6. Tighten eight Connectors. NOTE: To allow for Rod Cups and Rods, Dowels must be in the fourth hole up from the bottom.

Turn the adjusting screws on the Cabinet Hanger to level and plumb the Upright.

Important: A Wall Cleat is required between all Uprights taller than 48".



Hang Upright #7 onto the Wall Rail.


Insert two Double Dowels completely into the holes in the left Upright #7.

Insert four Push-In Dowels into Uprights #6 and #7. Fasten the Fixed Shelves to the Uprights. Tighten eight Connectors.

NOTE: To allow for Rod Cups and Rods, Dowels must be in the fourth hole up from the bottom.

Turn the adjusting screws on the Cabinet Hanger to level and plumb the Upright.

Important: A Wall Cleat is required between all Uprights taller than 48".



Hang Upright #8 onto the Wall Rail.


Insert four Push-In Dowels into Uprights #7 and #8. Fasten the Fixed Shelves to the Uprights. Tighten eight Connectors. Turn the adjusting screws on the Cabinet Hanger to level and plumb the Upright.

<u>IMPORTANT</u>: After all Uprights are level and plumb, Wall Cleats must be fastened to a wall stud or a Toggle Anchor.

NOTE: To allow for Rod Cups and Rods, Push-in Dowels must be in the fourth hole up from the bottom.

To add Rods, Doors, and Drawers, refer to the applicable pages listed in the Table of Contents.

Door Installation




Fasten the Hinges to the Door. Use the Black 1/2" Flat Head Screws.

Fasten the Doors to the Uprights. Use the screws in the hinges.

Drill a 3/16" hole and fasten the Pull or Knob to the Door. Fasten a Pull per Design to your Door placing them to the height of your preference.

Use the screws provide with the Knob or Pull.

Drawer Installation




Fasten the Extension Slides to your Drawer box Sides using the 9/16" Large Head screw as shown.

NOTE: Drawer Fronts are not bored for hole placement of Pulls and Knobs. Place the Drawer front face down onto a spoil board and drill 3/16" holes in your Drawer front specific to the Pull or Knob boring.

Fasten the Drawer Front to the Drawer Front Box using the 1-1/4" Large Head Screw supplied with the drawer slide Do not tighten the Screws at this time. Drawer fronts will be adjusted after you insert them into your cabinet.

Fasten the Pull to the Drawer Front and Drawer box front using the Machine Screws supplied with the Pull.

Drawer Installation




The rear hole for the 350mm Extension Rail requires boring. To do this, insert the tabs on the Rail Template Kit into the proper holes of the Upright. Use the Drill Bit supplied to drill the rear hole in the Template as shown in Diagram #1.

NOTE: The Lower Drawer Extension Rails will always use the 2nd hole up from the bottom. For 10" Large Drawers, use every 8th hole up as shown in Diagram #2. For 5" Small Drawers, use every 4th hole up. For every 10" Drawer, two 5" Drawers can be substituted.

Fasten the Extension Rails to the Upright. Use the 5/16" Flat Head Screws.

<u>NOTE</u>: The template is not needed if you are installing 450mm Extension Rails in your Closet Cabinets. Use the holes provided in the Uprights to fasten the 450mm Extension Rails to your Cabinet.

Shoe Shelf Installation



When locating a Shoe shelf in a Hang Cabinet, insert two Push-In Dowels into the 9th Upright holes below the top Fixed Shelf along the back edge.


Tighten the rear Connectors in the Shoe Shelf.

Next, insert two Push-In Dowels into the 11th Upright holes below the top Fixed Shelf along the front edge. The Shoe Shelf will rest on the front Push-In Dowels.

Then, insert the Shoe Fence into the holes along the front edge of the Shoe Shelf.

NOTE: For Shoe Shelf cabinets that hang side by side, a Double Dowel will be used to support the Shoe Shelves.

Rod Installation




Insert the tabs of the Rod Cups into the exact holes shown.

<u>NOTE</u>: There should be one hole exposed above the Rod Cups.


Cut a Rod to length and place it in the Rod Cups.

Adjustable Shelf Installation



Insert the Shelf Supports into the hole locations of your choice.

Place the Adjustable Shelves onto the Shelf Supports.




In some designs, you may need to cut an Adjustable Shelf to length to fit between two Uprights. Follow the diagrams and steps below for instructions.

Measure the opening between the Uprights for the finished cut length of the Adjustable Shelf as shown in Diagram #1.

With a hand saw or table saw, cut the Adjustable shelf to its finished length as shown in Diagram #2.


Push the template completely onto the cut edge and back edge of the Adjustable shelf as shown in Diagram #3. Drill through the template holes 1/2" deep using a 1/4" drill bit as shown in Diagram #3.

H-Joint Channel Installation



In some designs, you may have two Fixed Shelves that butt up to each other. For support between Fixed Shelves use the Corner Shelf H-Joint Channel as shown.

Bracket Kit Installation



Use a Bracket Kit for additional support for all 24"- 48" Hanging Cabinets.


To install the Bracket Kit, hold the bracket underneath the upright and strike a mark on the wall for the Wall Anchor.

Drill a 1/4" hole in the wall for the Wall Anchor. Turn the Wall Anchor into the hole until it is flush with the front surface of the wall.

Fasten the Bracket to the wall. Use the long Flat Head Screw.

Fasten the Bracket to the bottom edge of the Upright. Use the short Large Head Screw.

Hole Boring and Jig Installation




In some Designs, you may need to cut a Fixed Shelf to length and rebore holes to replace the connector holes in the Fixed Shelf.

- 1. Insert the shaft of the bit through the plastic sleeve as shown in Diagram #1.
- 2. Place the the stop over the shaft of the bit 2" from the end and tighten the set screw as shown in Diagram #2
 3. Cut the Fixed Shelf to length.
 4. Mark lines on the shelf as shown in Diagram #3.
 5. Line up the center line on the jig with the line on the Fixed Shelf as shown in Diagram #4.

- 6. Drill the holes in your shelf as shown in Diagram #4.


Cleat Dowel Boring Jig Installation




In some Designs, you may need to cut a Cleat to length and rebore holes to replace the Wood Dowels in a Cleat. Follow the diagram and steps below for instructions.

- Cut a Cleat to length.
 Place the template on the corner as shown with the finished surface text in the template on the finished surface of the Cleat.
 Drill two 5/16" diameter holes 1-1/16" deep through the template holes.
- 4. Push two Wood Dowels into the holes.


Cabinet Hanger Cover Installation





Place the Cabinet Hanger Cover onto the Cabinet Hanger as shown.

Weight limits



A WARNING

Please use your furniture correctly and safely. Improper use can cause safety hazards, or damage to your furniture or household items. *Carefully read the following chart*.

Look out for:	What can happen:	How to avoid the problem:
 Loose or unstable closet components. Tall closet component structures. Closet component structures that are over five feet tall and placed in an open area or a walk—in closet. 	Risk of injury Closet components that are not properly connected can easily slide against each other and cause the structure to be unstable and tip over. A tall closet structure can tip unless it is properly secured.	Closet components must be securely attached to each other from side to side, and top to bottom. Secure the closet structure to a wall stud whenever possible. If you cannot use a wall stud, use the supplied wall anchors into your drywall. (If attaching the product to a wall made of concrete, plaster, or other material, purchase and use the appropriate mounting hardware. The attachment hardware must be rated to provide a minimum of 100 pounds of pull strength.)
Overloaded drawers and shelves.	Risk of injury. Top-heavy furniture can tip over. Overloaded drawers or shelves can break.	Never exceed the weight limits shown in the instructions. Work from bottom to top when loading shelves and drawers. Place the heavier items on the lower shelves or in lower drawers.
Improper use of furniture to support TVs. Setting TVs on furniture items not intended to support them is hazardous.	Risk of injury. TVs can be very heavy. Plus the weight and location of the picture tube tends to make TVs unbalanced and prone to tipping forward.	• This product is not designed to support a television.
Children climbing or hanging on the shelves or clothing bars.	Risk of injury or death.	Do not allow children to climb or hang on the shelves or clothing bars. Avoid placing items like toys or candy on shelves.

SAUDER™ CLOSETS PRODUCTS LIMITED WARRANTY

SauderTM Closets provides limited lifetime warranty coverage on SauderTM Closets Products (the "Products") to the original first use retail consumer ("Consumer") as set forth in this limited warranty statement. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Limited Lifetime Warranty Coverage: SauderTM Closets warrants that the Products will be free from defects in material and workmanship under conditions of normal, residential use, for the lifetime of the Products. This limited warranty extends only to the original, first-use retail Consumer, and is not transferable.

Limitations on Warranty Coverage: Sauder™ Closets Limited Lifetime Warranty (described above) is the only warranty coverage provided by Sauder™ Closets for the Products, and is in lieu of all other warranties. Under the laws of certain states, there may be no implied warranties from Sauder™ Closets, and ALL IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED AND EXCLUDED TO THE FULLEST EXTENT ALLOWED BY LAW.

Exclusions from Coverage: This limited warranty does not cover defects arising from (1) the improper installation or use of the Products; (2) abuse or neglect; (3) any commercial, rental or non-residential use of the Products (including the installation and use of the Products in a commercial or rental structure); or (4) normal wear and tear.

Exclusive Remedy: SauderTM Closets will (at its option) repair or replace any defective Products (or components) at no charge, subject to confirmation of the defect and proof of purchase, as the sole and exclusive remedy under this limited warranty. This limited warranty does not cover costs for installation, returning any defective Products to SauderTM Closets, for removal or other labor costs in connection with the repair or replacement of the Products, all of which shall be the responsibility of the Consumer. SauderTM Closets liability under this limited warranty shall not exceed the purchase price of the Products. SauderTM Closets shall have NO LIABILITY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, and all such claims and damages are DISCLAIMED AND EXCLUDED FROM THIS LIMITED WARRANTY. You must notify SauderTM Closets, in writing, within 90 days after discovering any defect in order to receive limited warranty coverage.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

To Obtain Warranty Service or Information: For warranty inquiries or claims, contact SauderTM Closets at 1-855-854-7465, 502 Middle Street, Archbold, OH (USA) 43502, sauderclosets@ sauder.com. Return of any defective Product may be required by SauderTM Closets, or we may elect to examine the product at its location. If we ask you to ship any Products to us, we will issue you a return authorization number and provide return instructions. For returned Products to qualify for limited warranty coverage, they must be returned in the original or equivalent packaging, in accordance with the shipping instructions you receive from us, and must prominently display the return authorization number on the return package.

Stay Connected with SAUDER









Trust Sauder

Sauder has been making wood products since 1934. Today we offer a wide range of products, mostly made right here in Archbold, Ohio, and supported by our award-winning customer service.

Sauder™ Closets are supported by our Limited Lifetime Warranty and offers the same made-in-the-USA advantages as the rest of our product line.

Certificate of Conformity

- 1. This certificate applies to the Sauder Woodworking Product identified by this Instruction Book.
- 2. This certificate applies to compliance of this product with the CPSC Ban on Lead-Containing Paint (16 CFR 1303).
- 3. This product is manufactured by:

Sauder Woodworking Company 502 Middle Street Archbold, Ohio 43502 (419) 446-2711

4. Date of Manufacture:



register your new product online

For immediate service, our website is available 24 hours a day, 7 days a week to order replacement parts, register your product, and view Sauder™ Closets products. www.sauder-closets.com

Consumer Services in United States and Canada Mon.-Fri. – 9am-5:30pm ET(except holidays) 1-855-854-7465

