

MX-5 / Miata Handbrake Handle Removal Instructions

Removing the Original Handbrake Handle

The original handbrake handle is fitted very tightly and may require significant force to remove.

Step 1 – Grip the Handle

Using both hands, firmly grip the original handbrake handle.

Step 2 – Twist and Pull

While maintaining a firm grip, twist the handle left and right while pulling it towards the dashboard.

Important: The handle can be extremely tight from the factory. Considerable force may be required before it begins to move.

Step 3 – Lubricate if Required

If the handle is particularly stubborn, apply a small amount of washing-up liquid into the button hole at the top of the handbrake handle.

This will help lubricate the inside of the handle and make removal easier.

Step 4 – Remove the Handle

Continue twisting and pulling until the handle slides completely off the handbrake lever.

Installation

Fit your new replacement handle by sliding it onto the handbrake lever until fully seated.

Disclaimer

Please take care during installation and removal. Excessive force may be required. Just Send It Designs accepts no responsibility for damage caused during installation. If you are unsure about any part of the process, seek assistance from a qualified mechanic.