




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
★ 01	103 33 303 001	Hammer Case Assembly (incl. 42.43.59)	1	32	103 33 303 032	Rotor	1
02	103 33 303 002	Housing	1	33	103 33 303 033	End Plate	1
03	103 33 303 003	Motor Housing	1	35	103 33 303 035	BearingWasher	1
04	103 33 303 004	Trigger	1	36	103 33 303 036	Washer	1
05	103 33 303 005	Lock Ring	1	37	103 33 303 037	Hammer Pin	2
06	103 33 303 006	Air Inlet	1	38	103 33 303 038	Hammer Frame	1
07	103 33 303 007	O-Ring	1	39	103 33 303 039	Hammer	1
08	103 33 303 008	Spring	1	40	103 33 303 040	Bushing	1
10	103 33 303 010	Exhaust Deflector	1	42	103 33 303 042	Washer	1
11	103 33 303 011	Motor Housing	1	43	103 33 303 043	Hammer Case Bushing	1
12	103 33 303 012	Bushing	1	44	103 33 303 044	Pin	1
13	103 33 303 013	Valve Stem	1	46	103 33 303 046	Retainer	1
14	103 33 303 014	O-Ring	1	47	103 33 303 047	Thrust Washer	1
16	103 33 303 016	Spring Pin	1	48	103 33 303 048	Retainer	1
17	103 33 303 017	Reverse Knob	1	49	103 33 303 049	O-Ring	1
18	103 33 303 018	Pin	1	50	103 33 303 050	Throttle Valve Seat	1
19	103 33 303 019	Gasket	1	52	103 33 303 052	O-Ring	1
★ 20A	103 33 303 020	Throttle Valve Assembly (incl. 20A-1.20A-2)	1	53	103 33 303 053	O-Ring	1
20A-1	103 33 303 220	Pin	1	57	103 33 303 057	Needle Bearing	1
20A-2	103 33 303 320	Throttle Valve	1	58	103 33 303 058	Screw	2
21	103 33 303 021	Screw	4	59	103 33 303 059	Grease Fitting	1
22	103 33 303 022	O-Ring	1	60	103 33 303 060	Gasket	1
23	103 33 303 023	O-Ring	1	09	103 33 303 009	O-Ring	1
24	103 33 303 024	Reverse Valve	1	51	103 33 303 051	Socket Retainer	1
25	103 33 303 025	Pin	1	45A	103 33 303 045	1/2" Standard Anvil Assembly	1
26	103 33 303 026	Spring	1				
27	103 33 303 027	Bearing	1				
28	103 33 303 028	End Plate	1				
29	103 33 303 029	Spring Pin	3				
30	103 33 303 030	Cylinder	1				
31	103 33 303 031	Rotor Blade	7				