




NO.	PART NO.	DESCRIPTION	Qty	NO.	PART NO.	DESCRIPTION	Qty
★ 1	103 33 304 001	Housing Assembly (incl.21)	1	24	103 33 304 024	Pin	2
2	103 33 304 002	Backhead	1	25	103 33 304 025	O-Ring	2
3	103 33 304 003	Washer	1	26	103 33 304 026	Throttle Valve	2
4	103 33 304 004	Bushing	1	27	103 33 304 027	Throttle Valve Spring	2
★ 6	103 33 304 006	Standard Anvil Assembly (incl.6-1.6-2)	1	28	103 33 304 028	Screw	2
6-1	103 33 304 206	O-Ring	1	29	103 33 304 029	Bushing	1
6-2	103 33 304 306	Socket Retainer	1	30	103 33 304 030	Screw	1
7	103 33 304 007	Hammer Pin	2	31	103 33 304 031	Reverse Valve Knob	1
8	103 33 304 008	Hammer	2	★ 32	103 33 304 032	Air Inlet Assembly (incl.42)	1
9	103 33 304 009	Hammer Cam	1	33	103 33 304 033	Steel Ball Spring	1
10	103 33 304 010	Hammer Frame	1	34	103 33 304 034	Steel Ball	1
11	103 33 304 011	Throttle Lever	1	35	103 33 304 035	Valve Bushing	1
12	103 33 304 012	Front End Plate	1	36	103 33 304 036	O-Ring	1
13	103 33 304 013	Rotor	1	37	103 33 304 037	O-Ring	2
14	103 33 304 014	Rotor Blade	5	38	103 33 304 038	Spring Washer	2
15	103 33 304 015	Cylinder	1	39	103 33 304 039	O-Ring	1
16	103 33 304 016	Rear End Plate	1	40	103 33 304 040	O-Ring	1
17	103 33 304 017	Ball Bearing	1	41	103 33 304 041	Pin	1
18	103 33 304 018	Ball Bearing	1	42	103 33 304 042	Filter Screen	1
19	103 33 304 019	Pin	1				
20	103 33 304 020	Backhead Gasket	1				
21	103 33 304 021	Bushing	1				
22	103 33 304 022	Valve Stem	2				
23	103 33 304 023	Spring	2				

★ Must be Purchased in Assembly Set

A-BIS-D35-R120T108 A